

**Miele**

# Ovens

The cookbook



Dear connoisseurs,

Shared meals lead to good conversation and help create memorable occasions. Enjoying time with each other in this way connects us – especially when everything comes together perfectly. But surely this is something for everyday life and not just for those special moments.

Your new oven has been designed to achieve this very thing. This perfect all-rounder is not only ideal for preparing quick and healthy favourites, but also for conjuring up the kinds of culinary delights you might expect from a top class restaurant.

We hope that this book will inspire you and give you a genuine helping hand. Day in, day out, our Miele test kitchen is a hot pot of knowledge, curiosity, routine and the unexpected. From these ingredients, we have put together some handy tips and reliable recipes for you to use. For even more recipes, inspiration and exciting topics, have a look at our Miele@mobile app.

If you have any questions or requests, we would love to hear from you. Our contact details can be found at the end of this book.

We hope you enjoy many happy hours in the kitchen and around the table.

Kind regards, The Miele test kitchen team

# Contents

---

|                                       |    |
|---------------------------------------|----|
| <b>Foreword</b> .....                 | 3  |
| <b>About this book</b> .....          | 7  |
| <b>Overview of functions</b> .....    | 9  |
| <b>General notes</b> .....            | 11 |
| <b>Miele accessories</b> .....        | 15 |
| <b>Cakes</b> .....                    | 18 |
| Tips on preparation .....             | 19 |
| Apple sponge .....                    | 22 |
| Apple pie .....                       | 24 |
| Apricot tart with cream topping.....  | 26 |
| Belgian sponge cake.....              | 27 |
| Pear cake with an almond topping..... | 28 |
| Sponge cake base.....                 | 29 |
| Swiss roll sponge .....               | 30 |
| Butter cake .....                     | 32 |
| Baked cheesecake.....                 | 34 |
| Marble cake.....                      | 35 |
| Fruit tart (puff pastry).....         | 36 |
| Fruit tart (shortcrust pastry).....   | 37 |
| Sachertorte.....                      | 38 |
| Madeira cake .....                    | 39 |
| Chocolate nut cake .....              | 40 |
| Streusel cake with fruit .....        | 41 |
| <b>Baked goods</b> .....              | 42 |
| Biscuits .....                        | 43 |
| Blueberry muffins .....               | 44 |
| Linzer biscuits.....                  | 45 |
| Almond macaroons .....                | 46 |
| Shortbread biscuits .....             | 48 |
| Vanilla biscuits.....                 | 49 |
| Walnut muffins.....                   | 50 |
| Choux buns .....                      | 51 |
| <b>Bread</b> .....                    | 52 |
| Tips on preparation .....             | 53 |
| Baguettes .....                       | 56 |
| Swiss farmhouse bread.....            | 57 |
| Spelt bread.....                      | 58 |
| Flatbread .....                       | 59 |

---

|  |     |
|--|-----|
| Plaited loaf.....                              | 60  |
| Nut bread.....                                 | 61  |
| Mixed rye bread .....                          | 62  |
| Seeded loaf .....                              | 64  |
| Tiger bread .....                              | 66  |
| White loaf (in loaf tin) .....                 | 67  |
| White loaf (free form) .....                   | 68  |
| Dark mixed wheatgrain bread .....              | 69  |
| Ginger loaf.....                               | 70  |
| <b>Bread rolls</b> .....                       | 72  |
| Multigrain rolls .....                         | 72  |
| Rye bread rolls .....                          | 74  |
| White rolls.....                               | 76  |
| <b>Pizza and Co.</b> .....                     | 77  |
| Pizza (yeast-based dough).....                 | 78  |
| Pizza (quark dough).....                       | 80  |
| Savoury tart (puff pastry).....                | 82  |
| Savoury tart (shortcrust pastry).....          | 83  |
| <b>Meat</b> .....                              | 84  |
| Tips on preparation .....                      | 85  |
| Stuffed duck.....                              | 87  |
| Stuffed goose.....                             | 88  |
| Goose (without stuffing) .....                 | 90  |
| Chicken .....                                  | 91  |
| Chicken thighs.....                            | 92  |
| Stuffed turkey.....                            | 94  |
| Turkey thigh.....                              | 96  |
| Roast fillet of veal.....                      | 98  |
| Fillet of veal (low temperature cooking).....  | 100 |
| Veal knuckle .....                             | 101 |
| Roast saddle of veal.....                      | 102 |
| Saddle of veal (low temperature cooking).....  | 103 |
| Braised veal.....                              | 104 |
| Osso buco.....                                 | 105 |
| Rack of lamb with vegetables .....             | 106 |
| Leg of lamb.....                               | 108 |
| Roast saddle of lamb .....                     | 110 |
| Saddle of lamb (low temperature cooking).....  | 111 |
| Beef hash .....                                | 112 |
| Roast fillet of beef .....                     | 113 |
| Fillet of beef (low temperature cooking) ..... | 114 |

# Contents

---

|   |     |
|---|-----|
| Braised beef .....                                  | 115 |
| Roast sirloin joint.....                            | 116 |
| Roast sirloin joint (low temperature cooking) ..... | 117 |
| Yorkshire pudding .....                             | 118 |
| <b>Fish</b> .....                                   | 119 |
| Tips on preparation .....                           | 120 |
| Sea bream .....                                     | 121 |
| Trout .....   | 122 |
| Salmon fillet.....                                  | 123 |
| Salmon trout.....                                   | 124 |
| Pollock fillet .....                                | 125 |
| Pike perch fillet on vegetables .....               | 126 |
| <b>Bakes and gratins</b> .....                      | 127 |
| Swedish potato gratin .....                         | 128 |
| Potato gratin .....                                 | 129 |
| Potato and cheese gratin .....                      | 130 |
| Cheese soufflé.....                                 | 131 |
| Lasagne.....  | 132 |
| Moussaka .....                                      | 134 |
| Pasta bake.....                                     | 136 |
| Shepherd's pie .....                                | 137 |
| <b>Dessert</b> .....                                | 138 |
| Viennese apple strudel .....                        | 139 |
| Chocolate sponge puddings .....                     | 140 |

Before you begin, please take a few moments to read the hints we have put together on how to use this cookbook.

For each automatic programme, there is a suitable recipe that will help you get to grips with your Miele oven quickly.

Many of the automatic programmes allow you to select the end results that are just right for you – e.g. how well browned you want your bread and pastries to be or how well done you would like your meat.

## About the automatic programmes

- The automatic programmes are not available on every model. However, you can still cook all the recipes listed even if your oven does not feature the relevant automatic programmes. Simply refer to the manual settings instead. Any differences will be pointed out in the recipe method.
- Whenever a recipe involves the use of an automatic programme, you will find the path for selecting the programme listed in the settings section of the recipe.
- The programme duration specified for the automatic programmes is the average time determined in our test kitchen. However, the actual duration of many programmes will depend on how well done you want the food to be. You must select this level of cooking before starting the automatic programme.

## About the ingredients

- Unless stated otherwise, the weight indicated for meat is the trimmed, uncooked weight.
- The weight stated for fruit and vegetables always refers to the weight prior to peeling/shelling and pitting/coring.
- Prior to cooking, fruit and vegetables should always be cleaned/washed or, if necessary, shelled/peeled. Please note that this instruction will not be repeated as part of the recipe methods.

## About this book

---

### Special points concerning individual oven models

This cookbook is included with different sized ovens. When the ingredient quantities or settings deviate from one another, the settings to be selected are specified in the recipes in the following order:

- Ovens with 5 shelf levels
- [Ovens with 3 shelf levels] in square brackets
- (90 cm ovens) in round brackets

If the settings are the same for all ovens, they are shown without brackets.

If the Special application | Prove dough is not available on your oven, select the Automatic programme | Cakes | Yeast dough. Alternatively, use the Conventional heat function at a temperature of 30 °C and place a moist cloth over the dough.

If your oven does not feature the Moisture plus + Conventional heat, Moisture plus + Auto roast, Moisture plus + Fan plus or Moisture plus + Intensive bake functions, select the Moisture plus function. If using the Moisture plus + Conventional heat function, set the temperature to 20 °C lower than specified in the manual settings.

If your oven does not feature the Special application | Low temperature cooking function, use the Conventional heat function. Pre-heat the oven compartment at 120 °C for 15 minutes. Reduce the temperature to about 100 °C when you place the food in the oven.

For ovens with FlexiClip runners fitted above the rails of a shelf level, the racks and trays will sit slightly higher than they do on the standard shelf level: If possible, fit the FlexiClip runners one level lower than specified in the recipe and place the racks or trays on the FlexiClip runners.

If the FlexiClip runners in your oven are fitted between the side rails of a shelf level, use the shelf levels specified in the recipe.

### About the settings

- Times and temperatures: the recipes state time and temperature ranges. As a basic principle, allow yourself to be guided by the lower settings. You will then have the option of increasing the cooking time slightly if you feel this is necessary or if a test reveals that the food is not yet done.
- Shelf levels: the shelf levels for inserting trays and racks are numbered from lowest to highest.

## Moisture plus

For baking and roasting with moisture injection. Use this function for baking bread and pastries or for cooking fish and roasting meat.

With Moisture plus, bread comes out with a particularly even crumb (the inside of the bread) and crispy crust (crunchy on the outside but not brittle). Yeast-based doughs prove particularly well. Meat and fish are cooked gently and stay succulent.

Choose from the following combination options:

Moisture plus + Fan plus

Moisture plus + Conventional heat

Moisture plus + Auto roast

Moisture plus + Intensive bake

## Fan plus

For baking and roasting. You can cook on several shelf levels at the same time. Because the fan distributes the heat to food straight away, it allows you to use a lower temperature than you would with “Conventional heat”.

## Conventional heat

For baking and roasting traditional recipes, cooking soufflés and cooking at low temperatures. If using an older recipe or cookbook, set the oven temperature 10 °C lower than the recommended one. This will not change the cooking duration.

## Intensive bake

For baking items with a moist topping which require a crisp base. This function is not suitable for baking thin items or for roasting, as the items/juices will become too dark.

## Auto roast

For roasting. First, the oven compartment is automatically heated to a high searing temperature. As soon as this temperature has been reached, the oven automatically drops back down to the pre-selected cooking temperature. This browns the food beautifully on the outside and it can then finish cooking without you having to adjust the function.

# Overview of functions

---

## Bottom heat

Use this function towards the end of cooking to brown the base of the food.

## Top heat

Use this function towards the end of cooking to brown the top of the food being cooked.

## Full grill

For grilling thin cuts in large quantities and for browning large baked dishes. The whole of the top heat/grill element glows red to provide the required heat.

## Economy grill

For grilling thin cuts (e.g. steaks) in small quantities and for browning small baked dishes. Only the inner part of the heater element is switched on and glows red to provide the required heat.

## Fan grill

For grilling thicker cuts of meat (e.g. chicken). Because the fan distributes the heat to food straight away, it allows you to use a lower temperature than you would with the Grill function.

## Eco Fan heat

Suitable for small amounts, e.g. frozen pizzas, bake-off rolls and biscuits as well as meat dishes and roasts. You can save up to 30 % energy compared to cooking with a standard oven function – provided you keep the door shut during cooking.

## User programmes

You can create, save and name up to 20 user programmes. Combine up to 10 cooking stages for perfect results when making your favourite recipe. Or simply save your most frequent settings to make life easier for yourself. For each of the stages, you can select settings such as oven function, cooking temperature and duration, or core temperature.

## TasteControl

The TasteControl function is used to cool down the oven compartment and the food quickly once the food has been cooked. This prevents the food from burning or overcooking. When TasteControl is combined with the Keeping warm function, you can achieve optimum results in terms of timing and taste.

## Auto switch-off

Your oven features an intelligent electronic unit for maximum user convenience. At the end of the cooking duration, the oven will switch off automatically.

## Delay start

Enter a specific cooking duration or a time for “Ready at” or “Start at” to control what happens in advance. These settings will then switch off the oven automatically or cause it to come on and go off at the appropriate times.

## Cooking durations

You can set the required cooking duration in advance. The oven heating will switch off automatically once this duration has elapsed. If you select the “Pre-heating” function as well, the cooking duration will not commence until the selected temperature has been reached and the food has been placed in the oven.

## Pre-heating

It is only necessary to pre-heat the oven in a few instances. Most dishes can be placed in a cold oven. They will then make use of the heat produced during the heating-up phase. Further details are usually provided in the recipe. The pre-heating function should be used for the following dishes:

- Cakes, pastries and biscuits with a short cooking duration (approx. 30 minutes or less)
- Dark bread dough
- Beef sirloin joints and fillet

## Booster

To get the oven compartment up to the required temperature as quickly as possible, your oven has a Booster function. If you set a temperature higher than 100 °C with the Booster function enabled, the top heat/grill element and the ring heating element will come on together with the fan. This causes the oven to heat up much more quickly.

## Crisp function

For dishes that need that extra bit of crunch, use the Crisp function. By reducing the level of moisture inside the oven, this produces chips, pizzas and quiches that are beautifully crisp. And if you are cooking poultry, you can use it to make the skin nice and crispy while keeping the meat inside nice and succulent. The Crisp function can be used with any oven function and enabled whenever you need it.

# General notes

---

## Food probe

The food probe enables precise temperature-controlled cooking – some automatic programmes and special applications will specifically prompt you to use the food probe.

The metal tip of the food probe is inserted into the food and measures the core temperature of the food during cooking. The core temperature of the food reflects the progress of cooking. Set a lower or higher (max. 99 °C) core temperature, depending on whether you want your roast to be medium or well-done.

Application: the metal tip of the food probe must be fully inserted into the centre of the food. For smaller pieces of meat, you can use a piece of potato or meat trimmings (offcuts and sinews) to cover the protruding thermometer part. Otherwise the displayed core temperature may be incorrect.

## Special applications

Your oven offers a variety of special applications, depending on which features have been included. A few of these are presented below.

### Prove dough

For proving dough easily and reliably. You can select a proving time of 15, 30 or 45 minutes. Leave the dough to prove uncovered in the moist, warm oven compartment until it has doubled in volume.

### Low temp. cooking

For the cooking of particularly tender meat. The low temperature and extra-long cooking duration produce meat that is cooked to perfection and beautifully tender.

### The ABC of cooking

| Term          | Explanation  |
|---------------|--|
| Cracking      | Term for desired breaks in the crust of baked goods.   |
| Boned         | Fish or meat that has had the bones removed.   |
| Fracturing    | Fracturing refers to the small hairline cracks that develop on a crust.  |
| Ready to cook | Food that has been trimmed/prepared but not yet cooked. Examples include meat that has had the fat and sinews removed; fish that has been scaled, gilled and gutted; or fruit and vegetables that have been washed and peeled/shelled. |
| Dough piece   | A worked and shaped piece of raw dough.  |
| Dough seam    | Term for the join in the bread that develops during shaping.   |
| Crusty        | Term for the flaky texture of the crust.   |
| Rounding      | Technique for shaping bread and bread rolls. You can find a precise description in the “Bread & rolls” chapter.  |

# General notes

---

## Quantities and weights

tsp = teaspoon

tbsp = tablespoon

g = gram

kg = kilogram

ml = millilitre

Pinch = a small amount

### **1 teaspoon is approx.**

- 3 g baking powder
- 5 g salt/sugar/vanilla sugar
- 5 g flour
- 5 ml liquid

### **1 tablespoon is approx.**

- 10 g flour/cornflour/breadcrumbs
- 10 g butter
- 15 g sugar
- 10 ml liquid
- 10 g mustard

## Accessories

With our extensive range of accessories, we can help you achieve the best possible results. Each component has been designed specifically for Miele ovens in terms of size and functionality. All have undergone rigorous testing to ensure that they meet exacting Miele standards. All products can be easily purchased from the Miele online shop, from Miele directly or from specialist retailers.

### PerfectClean

Cleaning has never been easier! Thanks to the unique PerfectClean finish that has been applied to the oven compartment, freshly deposited soiling can be effortlessly removed.

This special technology is also used on Miele baking trays and dishes, which means that there is generally no need for baking parchment. Bread, rolls and biscuits will slide off as if by magic instead of getting stuck to the base, sides and edges.

The surface is so resistant that you can even cut pizza and cake etc. directly on the tray/base without damaging it. And once you have finished, everything wipes clean in a flash.

### Baking tray

The flatter baking tray is perfect for all dishes that only release a small amount of liquid during baking or cooking. For example, it can be used for biscuits, bread, chips and roasted vegetables.

### Universal tray

Use the deeper universal tray for deeper, filled cakes, for catching meat juices or for gently roasting meat.

### Gourmet baking tray

The perforated gourmet baking tray has been specially developed for the Moisture plus function. It is particularly well suited for baked goods made using fresh yeast-based dough and quark and oil dough, bread and bread rolls. The tiny perforations assist in browning the underside of baked goods.

The gourmet baking tray is also suitable for drying or desiccating fruit and vegetables.

### Round baking tray

The round baking tray is ideal for cooking anything circular, such as pizzas, quiches and tarts.

The PerfectClean finish generally eliminates the need to grease the dish or line it with baking parchment. To help you make the most of the Moisture plus function, a perforated version of the round baking tray is also available.

# Miele accessories

---

## Grilling and roasting insert

The grilling and roasting insert is placed on the universal tray to prevent the food from sitting in the juices that escape during the cooking process. This keeps the outside crisp and prevents the juices from caking. The collected juice is perfect for making stock.

The ridged and grooved shape of the grilling and roasting insert also prevents grease spatter and excessive soiling in the oven compartment.

## Miele Gourmet oven dish

The Miele Gourmet oven dish has been designed to close the gap between cooking on the hob and cooking inside the oven. Once you have finished using it on the hob, the Gourmet oven dish can be easily inserted into the side runners of the oven compartment.

Basting with meat juices or stirring is particularly convenient thanks to the FlexiClips as you can simply pull the Gourmet oven dish out of the oven compartment instead of lifting it out.

The Gourmet oven dish has a non-stick coating and is suitable for cooking stews, meat, soups, sauces, bakes and even desserts. Suitable lids are also available.

## FlexiClip runners

The FlexiClip runners enable individual trays or racks to be pulled out safely and conveniently. They can be easily positioned at different levels in the oven and can also be conveniently moved to another level. The FlexiClip runners are available with a PerfectClean finish or as a PyroFit version.

## Care products

Regular cleaning and care will help you get the most from your oven by keeping it in good working order and maximising its lifespan. Original Miele care products have been designed to be perfectly compatible with Miele ovens. These products can be easily purchased from the Miele online shop, from Miele directly or from specialist retailers.

### Miele oven cleaner

The stand-out features of Miele oven cleaner are that it is extremely tough on grease and is very easy to use. Thanks to its gel-like consistency, it also clings to the oven walls. Its special formula makes for effortless cleaning and a short contact time without any need for heating.

### Descaling tablets

Miele has developed special descaling tablets for the water pipework and containers. Descaling is not only highly effective, but it is also particularly gentle on the materials.

### Miele MicroCloth Kit

This set of cloths effortlessly removes finger marks and light soiling. Included in the kit are a universal cloth, a glass cloth and a polishing cloth. The hard-wearing cloths are made from finely woven microfibres and offer high cleaning performance.

# Cakes

---

## Truly scrumptious

A beautifully set table and stimulating discussions are some of the ingredients you will need for an enjoyable coffee morning or a cosy afternoon tea. The others – of course – are delicious cakes and gateaux. If you want to spoil your guests (and yourself!) with delicious homemade treats, your only problem will be choosing between the vast array of options. Do you want it to be fruity? Or creamy? Or do you like a bit of crunch? Perhaps the best course of action is to offer a bit of everything. After all, sweet treats are the ideal comfort food and will have everybody coming back for more.

## Tips on preparation

Get the best results when baking with a few simple tips. The Miele test kitchen would like to share some of its expert knowledge with you.

## Raising agents

Raising agents are used to make the dough or cake mix rise and help it stay light and airy after kneading or mixing.

### Yeast

Yeast is a natural raising agent to help dough leaven. Fresh and dry yeast are equally suitable for baking. To create a rise, the yeast organisms require heat (temperatures from 35 °C to a maximum of 40 °C), time and nutrition in the form of flour, sugar and liquid.

## Baking powder

Baking powder is the most common chemical raising agent. The tasteless white powder made primarily from sodium carbonate is very versatile and can be used for various dough types.

## Bicarbonate of soda

Bicarbonate of soda is a white powder with a mild, slightly alkaline taste. It is a constituent of baking powder and also speeds up the cooking of pulses.

# Cakes

---

## Dough and mixtures

### Sponge mixture

Sponge mixture is a lighter, delicate dough. This texture is achieved by beating egg yolks and whole eggs and folding into stiffly whipped egg whites.

#### Tips for making the mixture:

It is best to use eggs at room temperature.

Beat the egg white mixture as much as possible.

#### Tips for baking:

Don't let the cake become too dark. Otherwise the top of the cake will harden and may crack more easily.

#### Tips after baking:

The warm cake can be removed from the baking parchment more easily if you moisten the bottom of the parchment with some water.

If the sponge is going to be the basis for a layered cake, you should bake it the day before as this will make cutting easier and more accurate.

To divide the cake horizontally, it is best to use a sharp knife to make cuts at regular intervals around the outside of the cake. Insert a thread into the cuts and cross the ends at the front. Pulling the ends of the thread apart will divide the cake evenly into 2 bases.

### Puff pastry

Puff pastry consists of multiple layers that open up and flake during baking.

#### Tips:

Do not knead any leftover pieces of dough because this will stop the pastry from flaking. It is better to place the dough pieces on top of each other and roll them out again.

Adding moisture during the first cooking stage improves the flakiness of the pastry and creates a wonderful shine on the pastry surface.

### Choux pastry

A unique method is required to make this pastry. The dough is “cooked out” in a saucepan and then baked.

#### Tips:

It is essential to leave the oven door closed during the first 10 minutes of baking. The choux pastry is so sensitive during this time that opening the door would stop the pastry becoming light and airy.

Fill choux buns or éclairs just before serving. This keeps them nice and crisp.

## Shortcrust pastry

Shortcrust pastry comes out particularly well when baked in ovens with a moisture function because the steam supplied to the dough makes the texture particularly good.

### Tips:

Only knead your dough for a short time because a long kneading time will take away the desired crumbly consistency of the pastry.

In order to achieve a short kneading time, use soft fat where possible.

The chilling time after kneading enhances the desired crumbly consistency of the finished bake.

When rolling out the dough, use as little flour as possible. This will allow the dough to retain its elasticity.

Leftover pieces of dough can always be kneaded together again. If the dough turns too crumbly, just add some water.

Shortcrust pastry can be prepared in advance. When packaged correctly, it can stay fresh for 2–3 days in the fridge.

## Batter

Batter is a creamy to viscous dough that is mainly made from fat, sugar and eggs. These ingredients ensure that the cake is nice and moist.

### Tips:

Cream the sugar and butter and mix in the other ingredients quickly.

All ingredients used should be at room temperature.

If the consistency of the batter becomes too stiff, you can add some liquid, for example milk.

Dust fruit, nuts and chocolate chips with some flour and mix them into the batter just before baking. This keeps these ingredients evenly distributed in the cake during baking.

Bake the batter as soon as it has been made.

To test if the cake is done, simply insert a wooden skewer into the cake. The cake is cooked through when the skewer comes out without any moist cake crumbs sticking to it.

The warm cake can be removed from the baking parchment more easily if you moisten the bottom of the parchment with some water.

## Quark dough

Quark dough is a quick alternative to yeast-based dough and has a very similar end result when it is freshly baked.

### Tips:

Only knead the ingredients for a short time. Otherwise there is a risk that the dough will become too sticky.

Bake the dough as soon as you have made it.

# Cakes

---

## Apple sponge

Total time required: 95 minutes

Serves 12

### For the topping

500 g apples, tart/sour

### For the batter

150 g softened butter

150 g caster sugar

8 g vanilla sugar

3 medium eggs

2 tbsp lemon juice

150 g plain white flour

½ tsp baking powder

### For the tin

1 tsp butter

### For dusting

1 tbsp icing sugar

### Accessories

Rack

Springform cake tin, Ø 26 cm

Fine sieve

### Method

Peel and quarter the apples. Cut into the outside of each apple quarter (opposite side to the core), making cuts approx. 1 cm apart. Mix with the lemon juice and put to one side.

Grease the springform tin.

Cream together the butter, sugar and vanilla sugar for approximately 2 minutes. Stir in the eggs one at a time (½ minute each).

Place the rack in the oven. Start the automatic programme or pre-heat the oven.

Sift together the flour and baking powder and mix with the other ingredients.

Pour the mixture into the springform tin, spreading it evenly. Press the apples gently into the mixture with the core side down.

Place the springform tin in the oven and bake until golden.

Leave the cake in the tin for 10 minutes. Then, remove from the tin and allow to cool on the rack. Dust with icing sugar.

## Settings

### Automatic programme

Cakes | Apple sponge

Programme duration:

63 [65] (65) minutes

### Manual

Oven functions: Conventional heat

Temperature: 170–180 °C

Booster: Off

Pre-heat: On

Crisp function: Off (On) [Off]

Duration: 45–55 minutes

Shelf level: 2 [1] (1)

### Tip

As an alternative to dusting the cake with icing sugar, try an apricot glaze instead. To create the glaze, gently heat some apricot jam and stir it until smooth.

# Cakes

---

## Apple pie

Total time required: 140 minutes

Serves 12

### For the dough

200 g softened butter

100 g caster sugar

16 g vanilla sugar

1 medium egg

350 g plain white flour

1 tsp baking powder

1 pinch of salt

### For the topping

1.25 kg apples

50 g raisins

1 tbsp lemon juice

½ tsp ground cinnamon

50 g caster sugar

### For the tin

1 tsp butter

### For glazing

100 g icing sugar

2 tbsp warm water

### Accessories

Springform cake tin, Ø 26 cm

Cling film

Rack

### Method

To make the dough, cream together the butter, sugar, vanilla sugar and egg. Sift in the flour, baking powder and salt and knead together. Chill the dough for one hour.

Peel the apples and slice them into wedges. Mix them together with the raisins, lemon juice and cinnamon.

Grease the springform tin.

Divide the dough into 3 portions. Roll out the first portion on the base of the springform tin. Assemble the springform tin. Make the second portion into a long roll and press it around the edge of the tin so that it is around 4 cm high. Prick the base several times with a fork.

Place the rack in the oven. Start the automatic programme or pre-heat the oven.

Place the third portion of the dough between 2 layers of cling film and roll it out to the size of the springform tin.

Mix the sugar with the apples and then spread them over the pastry base. Put the pastry lid on top and pinch the edges to seal.

Place the springform tin in the oven and bake.

Allow to cool in the tin for 10 minutes. Then, remove from the tin and allow to cool on the rack.

Mix the icing sugar with the water and brush it on.

## **Settings**

### **Automatic programme**

Cakes | Apple pie

Programme duration:

77 [70] (78) minutes

### **Manual**

Oven functions: Conventional heat

Temperature: 185–195 °C

Booster: Off

Pre-heat: On

Crisp function: On

Duration: 55–65 minutes

Shelf level: 2 [1] (1)

# Cakes

---

## Apricot tart with cream topping

Total time required: 80 minutes

Serves 12

### For the dough

250 g plain white flour

1 tsp baking powder

125 g butter

125 g caster sugar

1 medium egg

### For the topping

480 g tinned apricots (drained weight)

### For the topping

250 ml double cream

2 medium eggs

2 tbsp cornflour

16 g vanilla sugar

½ lemon, juice only

### For the tin

1 tsp butter

### Accessories

Springform cake tin, Ø 26 cm

Rack

### Method

Mix together the flour, baking powder, butter, sugar and egg and knead to form a smooth dough. Grease the springform tin. Spread the mixture evenly over the base of the springform tin.

Place the apricots on top of the mixture with the curved side facing upwards.

Mix together all the ingredients for the topping. Spread the topping over the apricots.

Place on the rack in the oven and bake until golden.

### Settings

Oven functions: Intensive bake

Temperature: 160–170 °C

Pre-heat: Off

Crisp function: On

Duration: 50–60 minutes

Shelf level: 2 [1] (1)

## Belgian sponge cake

Total time required: 80 minutes

Serves 12

### Ingredients

4 medium eggs

250 g butter

250 g caster sugar

1 tsp salt

250 g plain white flour

3 tsp baking powder

100 g chocolate drops

1 tsp ground cinnamon

### For the tin

1 tsp butter

### Accessories

Springform cake tin, Ø 26 cm

Rack

### Method

Separate the egg whites from the yolks. Cream together the butter, sugar, salt and egg yolks.

Beat the egg whites until stiff. Carefully fold half of the egg white mixture into the sugar and egg yolk mixture. Sift together the flour and baking powder and add them to the main mixture. Fold in the rest of the egg white mixture.

Fold in the chocolate drops and cinnamon.

Grease the springform tin and fill with the mixture.

Place the rack in the oven. Start the automatic programme or pre-heat the oven using the settings indicated for cooking stage 1.

Manual settings:

Adjust settings as indicated for cooking stage 2.

Place the springform tin in the oven and bake until golden brown.

### Settings

#### Automatic programme

Cakes | Belgian sponge cake

Programme duration: 65 minutes

#### Manual

Cooking stage 1

Oven functions: Conventional heat

Temperature: 190 °C

Booster: On

Pre-heat: On

Crisp function: Off

Shelf level: 2 [1] (2)

Cooking stage 2

Temperature: 150–180 °C

Duration: 60–65 minutes

#### Tip

For a more intense taste, replace 50 g of the sugar with honey. You can enhance the flavour of the mixture by adding dried fruit, chopped nuts or vanilla extract to taste.

# Cakes

---

## Pear cake with an almond topping

Total time required: 95 minutes

Serves 20

### For the base

470 g plain white flour

125 g caster sugar

20 g vanilla sugar

250 g butter

1 medium egg

### For the topping

3 tins of pears (460 g each)

### For the topping

550 ml crème fraîche

2 tbsp cornflour

4 medium eggs

65 g caster sugar

2 tsp cinnamon

40 g flaked almonds

### Accessories

Universal tray

### Method

Mix together the flour, sugar, vanilla sugar, butter and egg and knead to form a smooth batter. Roll the mixture out onto the universal tray.

Cut the pears into slices 1 cm thick and arrange evenly on top of the mixture.

Mix together the crème fraîche, cornflour, eggs, sugar, vanilla sugar and cinnamon.

Pour the topping over the pears. Scatter with flaked almonds.

Place the universal tray in the oven and bake until pale yellow.

### Settings

Oven functions: Intensive bake

Temperature: 150–160 °C

Pre-heat: Off

Crisp function: On

Duration: 60–70 minutes

Shelf level: 2 [1] (1)

## Sponge cake base

Total time required: 75 minutes

Serves 16

### For the batter

4 medium eggs  
4 tbsp hot water  
175 g caster sugar  
200 g plain white flour  
1 tsp baking powder

### For the tin

1 tsp butter

### Accessories

Rack  
Fine sieve  
Springform cake tin, Ø 26 cm  
Baking parchment

### Method

Separate the egg whites from the yolks. Beat the egg whites with the water until stiff. Slowly add the sugar, beating after each addition. Then fold in the beaten egg yolk.

Place the rack in the oven. Start the automatic programme or pre-heat the oven.

Mix the flour and baking powder, sieve into the egg mixture and fold in with a large whisk.

Grease the base of the springform tin and line with baking parchment. Pour the mixture into the tin and spread it out evenly.

Place the cake in the oven and bake until golden.

After baking, allow to cool in the tin for 10 minutes. Then, remove from the tin and allow to cool on the rack. Slice the cake horizontally to make three separate layers.

Spread with the prepared filling.

### Settings

#### Automatic programme

Cakes | Sponge base

Programme duration:

46 [47] (47) minutes

#### Manual

Oven functions: Conventional heat

Temperature: 160–170 °C

Booster: Off

Pre-heat: On

Crisp function: Off

Duration: 30–40 minutes

Shelf level: 2 [1] (1)

### Tip

To make a chocolate sponge, add 2–3 teaspoons of cocoa powder to the flour mixture.

# Cakes

---

## Swiss roll sponge

Total time required: 55 minutes

Serves 16

### For the batter

190 (290) g caster sugar  
8 (12) g vanilla sugar  
1 pinch (2 pinches) of salt  
125 (190) g plain white flour  
70 (110) g cornflour  
1 (1½) tsp baking powder  
4 (6) medium eggs  
4 (6) tbs hot water

### For the tin

1 tsp butter

### Accessories

Fine sieve  
Baking tray or universal tray  
Baking parchment  
Kitchen towel

### Method

Mix together the sugar, vanilla sugar and salt in a bowl. In a separate bowl, sift together the flour, cornflour and baking powder.

Start the automatic programme or pre-heat the oven.

Separate the egg whites from the yolks. Beat the egg whites with the hot water until stiff. Slowly add the sugar mixture, stirring after each addition. Slowly beat in the egg yolks.

Sift the flour mixture over the egg and sugar mixture. Fold it in with a large whisk.

Grease the baking tray or universal tray and line with baking parchment. Spread the mixture evenly over the parchment.

Place the Swiss roll sponge in the oven and bake.

If you intend to use the sponge to make a Swiss roll, turn it out onto a damp kitchen towel as soon as it has finished baking, pull off the baking parchment and roll up. Allow to cool.

Spread with the prepared filling.

## **Settings**

### **Automatic programme**

Cakes | Swiss roll

Programme duration:

25 [24] (26) minutes

### **Manual**

Oven functions: Conventional heat

Temperature: 180–190 °C

Booster: On

Pre-heat: On

Crisp function: Off

Duration: 15–25 minutes

Shelf level: 1

# Cakes

---

## Butter cake

Total time required: 95 minutes

Serves 20 (30)

### For the batter

42 (63) g fresh yeast  
200 (300) ml lukewarm milk, 3.5 % fat  
500 (750) g strong white flour  
50 (80) g sugar  
 $\frac{1}{2}$  ( $\frac{3}{4}$ ) tsp salt  
50 (80) g softened butter  
1 (2) medium egg(s)

### For the topping

100 (150) g softened butter  
100 (150) g flaked almonds  
120 (180) g sugar  
16 (24) g vanilla sugar

### Accessories

Baking tray or universal tray

### Method

Stir the yeast into the milk to dissolve it. Mix together with the remaining ingredients and knead for 3–4 minutes until you have a smooth dough.

Shape the dough into a ball and place it in a bowl in the oven compartment. Cover with a damp cloth. Prove the dough using the settings indicated for proving phase 1.

Lightly knead the dough and then roll it out on a baking tray or the universal tray. Cover and prove the dough using the settings indicated for proving phase 2.

To make the topping, mix together the butter, vanilla sugar and half of the sugar. Make little wells in the dough with your fingers. Pour the butter-sugar mixture into the wells. Spread the remaining sugar and flaked almonds over the dough.

With automatic programme:  
Start the Automatic programme and place the cake in the oven.

Manual settings:  
Leave to prove at room temperature for another 10 minutes. Then place the cake in the oven and bake until golden.

## **Settings**

### **Prove dough**

Proving phases 1 and 2

Oven functions: Conventional heat

Temperature: 30 °C

Proving time: 20 minutes for each phase

## **Baking**

### **Automatic programme**

Cakes | Butter cake

Programme duration:

32 [34] (30) minutes

## **Manual**

Oven functions: Conventional heat

Temperature: 175–185 °C

Booster: Off

Pre-heat: Off

Crisp function: Off

Duration: 20–30 minutes

Shelf level: 2

# Cakes

---

## Baked cheesecake

Total time required: 170 minutes

Serves 20

### For the base

340 (530) g plain white flour

4 (6) tsp baking powder

180 (280) g sugar

2 (3) medium eggs, yolks only

180 (280) g butter

### For the topping

4 (6) medium eggs

2 (3) medium eggs, whites only

460 (700) g sugar

18 (28) g vanilla sugar

85 g (119 g) custard powder (vanilla)

2 (4) tsp lemon extract or butter-vanilla  
flavouring

2.3 (3.5) kg low-fat quark

### Accessories

Universal tray

### Method

To create the base, make a shortcrust pastry from the dough ingredients. Chill for approx. 60 minutes.

Roll the mixture out onto the universal tray. Form a rim up to the top edge of the universal tray. Prick the base several times with a fork.

Mix together all the ingredients for the topping. Spread the mixture evenly over the base.

Place the cake in the oven and bake.

At the end of cooking, leave the cake in the oven compartment for 5 minutes with the oven switched off.

### Settings

Oven functions: Intensive bake

Temperature: 150–160 °C

Pre-heat: Off

Crisp function: On

Duration: 70–80 minutes

Shelf level: 2 [1] (1)

## Marble cake

Total time required: 80 minutes

Serves 18

### For the batter

250 g softened butter

200 g caster sugar

8 g vanilla sugar

4 medium eggs

200 ml soured cream

400 g plain white flour

16 g baking powder

1 pinch of salt

3 tbsp cocoa powder

### For the tin

1 tsp butter

### Accessories

Ring tin, Ø 26 cm

Rack

### Method

Cream together the butter, sugar and vanilla sugar. Add the eggs one by one, stirring for ½ minute each time. Add the soured cream. Mix together the flour, baking powder and salt. Then stir into the other ingredients.

Grease the ring tin and put half of the mixture into it.

Stir the cocoa powder into the other half of the mixture. Pour the dark mixture over the light mixture. Swirl a fork through the mixture to give a marbled effect.

Place the ring tin on the rack in the oven and bake.

Leave the cake in the tin for 10 minutes. Then, remove from the tin and allow to cool on the rack.

### Settings

#### Automatic programme

Cakes | Marble cake

Programme duration: 55 minutes

#### Manual

Oven functions: Fan plus

Temperature: 150–160 °C

Booster: On

Pre-heat: Off

Crisp function: Off

Duration: 50–60 minutes

Shelf level: 2 [1] (1)

# Cakes

---

## Fruit tart (puff pastry)

Total time required: 60 minutes

Serves 8

### For the pastry

230 g puff pastry

### For the topping

30 g ground hazelnuts

500 g fruit (e.g. apricots, plums, pears, apples, cherries) chopped into small pieces

### For the topping

2 medium eggs

200 ml double cream

50 g caster sugar

1 tsp vanilla sugar

### Accessories

Round baking tray, Ø 27 cm

Rack

### Method

Line the baking tin with the pastry dough and sprinkle over the ground hazelnuts.

Arrange the fruit pieces on top of the dough.

Insert the rack. Start the automatic programme or pre-heat the oven using the settings indicated for cooking stage 1.

For the topping, mix together the eggs, cream, sugar and vanilla sugar and pour over the fruit.

Manual settings:

Adjust settings as indicated for cooking stage 2.

Place the fruit tart in the oven and bake until golden brown.

### Settings

#### Automatic programme

Cakes | Fruit flan | Puff pastry

Programme duration: 36 minutes

#### Manual

Cooking stage 1

Oven functions: Fan plus

Temperature: 230 °C

Booster: On

Pre-heat: On

Crisp function: On

Shelf level: 1

Cooking stage 2

Oven functions: Conventional heat

Temperature: 220–230 °C

Booster: On

Pre-heat: On

Crisp function: On

Duration: 36–42 minutes

## Fruit tart (shortcrust pastry)

Total time required: 120 minutes

Serves 8

### For the pastry

200 g plain white flour

65 ml water

80 g butter

¼ tsp salt

### For the topping

30 g ground hazelnuts

500 g fruit (e.g. apricots, plums, pears, apples, cherries) chopped into small pieces

### For the topping

2 medium eggs

200 ml double cream

50 g caster sugar

1 tsp vanilla sugar

### Accessories

Round baking tray, Ø 27 cm

Rack

### Method

Dice the butter and mix with the flour, salt and water and rapidly knead to form a smooth dough. Chill for 30 minutes.

Line the baking tin with the pastry dough and sprinkle over the ground hazelnuts.

Arrange the fruit evenly on top of the dough.

Insert the rack. Start the automatic programme or pre-heat the oven using the settings indicated for cooking stage 1.

For the topping, mix together the eggs, cream, sugar and vanilla sugar and pour over the fruit.

Manual settings:

Adjust settings as indicated for cooking stage 2.

Place the fruit tart in the oven and bake.

### Settings

#### Automatic programme

Cakes | Fruit flan | Shortcrust pastry

Programme duration: 43 minutes

#### Manual

Cooking stage 1

Oven functions: Fan plus

Temperature: 230 °C

Booster: On

Pre-heat: On

Crisp function: On

Shelf level: 1

Cooking stage 2

Oven functions: Conventional heat

Temperature: 220–240 °C

Booster: On

Pre-heat: On

Crisp function: On

Duration: 36–45 minutes

# Cakes

---

## Sachertorte

Total time required: 70 minutes

Serves 12

### For the batter

130 g dark chocolate

140 g butter

110 g icing sugar

8 g vanilla sugar

6 medium eggs

1 pinch of salt

110 g caster sugar

140 g plain white flour

1 tsp baking powder

### For glazing

200 g apricot jam

### For the glaze

200 g caster sugar

125 ml water

150 g dark chocolate

### Accessories

Fine sieve

Rack

Springform cake tin, Ø 24 cm

Baking parchment

### Method

Melt the chocolate.

Cream together the butter and icing sugar.

Separate the egg whites from the yolks. Stir in the egg yolk. Stir in the chocolate.

Sift the flour and mix together with the baking powder. Beat the egg whites with the salt and sugar until stiff.

Alternately add the flour mixture and the egg whites to the batter.

Place the rack in the oven. Start the automatic programme or pre-heat the oven.

Line the springform tin with baking parchment and pour in the batter. Place in the oven compartment and bake.

Leave the cake base to cool. In the meantime, heat up the apricot jam on the hob and strain it through a sieve.

Slice the cake base and brush the sieved apricot jam over the cut surfaces and the sides.

To make the glaze, bring the sugar and water to the boil, add the chocolate and allow to melt.

Spread the chocolate glaze evenly over the Sachertorte.

### Settings

#### Automatic programme

Cakes | Sachertorte

Programme duration: 55 minutes

#### Manual

Oven functions: Conventional heat

Temperature: 170 °C

Booster: On

Pre-heat: On

Crisp function: On for 10 minutes after placing the cake in the oven

Duration: 55 minutes

Shelf level: 2 [1] (2)

## Madeira cake

Total time required: 100 minutes

Serves 18

### For the batter

250 g softened butter

250 g caster sugar

8 g vanilla sugar

4 medium eggs

200 g plain white flour

100 g cornflour

2 tsp baking powder

1 pinch of salt

### For the tin

1 tsp butter

1 tbsp breadcrumbs

### Accessories

Rack

Loaf tin, 30 cm long

### Method

Grease the tin and sprinkle with breadcrumbs.

Place the rack in the oven. Start the automatic programme or pre-heat the oven.

Beat the butter with the sugar and vanilla sugar until fluffy. Stir in the eggs one after another.

Mix together the flour, cornflour, baking powder and salt. Then fold into the other ingredients.

Fill the loaf tin with the mixture and place it lengthways on the rack in the oven. Bake.

Leave the cake in the tin for 10 minutes. Then, remove from the tin and allow to cool on the rack.

### Settings

#### Automatic programme

Cakes | Madeira cake

Programme duration:

78 [83] (78) minutes

#### Manual

Oven functions: Conventional heat

Temperature: 155–165 °C

Booster: Off

Pre-heat: On

Crisp function: On

Duration: 60–70 minutes

Shelf level: 2 [1] (1)

# Cakes

---

## Chocolate nut cake

Total time required: 75 minutes + 12 hours for chilling

Serves 16

### Ingredients

200 g butter

250 g dark chocolate

250 g ground hazelnuts

160 g caster sugar

3 tbsp espresso

1 tsp bourbon vanilla essence

6 medium eggs

### For the tin

1 tbsp butter

### Accessories

Springform cake tin, Ø 26 cm or

24 small ramekins (100 ml each)

Baking parchment

Rack

### Method

Melt the butter and chocolate. Add the hazelnuts, sugar, espresso and bourbon vanilla essence. Allow to cool.

Separate the egg whites from the yolks. Fold the egg yolks into the butter and chocolate mixture. Whisk the egg whites until stiff and fold into the mixture.

Start the automatic programme or pre-heat the oven.

Grease the springform tin and line with baking parchment or grease the ramekins. Pour the mixture into the springform tin or into the ramekins.

Place on the rack in the oven and bake.

Chill for 12 hours before serving.

### Settings

#### Automatic programme

Cakes | Chocolate hazlenut cake | One large / Several small

Programme duration One large:

55 minutes

Programme duration Several small:

40 [28] (40) minutes

#### Manual

##### One large

Oven functions: Fan plus

Temperature: 150 °C

Booster: On

Pre-heat: On

Crisp function: Off

Duration: 55 minutes

Shelf level: 2 [1] (1)

##### Several small

Oven functions: Fan plus

Temperature: 150 °C

Booster: On

Pre-heat: On

Crisp function: Off

Duration: 40 [28] (40) minutes

Shelf level: 2 [1] (2)

### Tip

Serve with fresh berries.

For 12 ramekins, reduce the quantity by half. The cooking duration stays the same.

## Streusel cake with fruit

Total time required: 150 minutes

Serves 20 (30)

### For the batter

42 (63) g fresh yeast  
150 (220) ml lukewarm milk, 3.5 % fat  
450 (680) g strong white flour  
50 (80) g sugar  
90 (140) g softened butter  
1 (2) medium egg(s)

### For the topping

1.25 (1.9) kg apples

### For the streusel crumble

240 (360) g plain white flour  
150 (230) g sugar  
16 (24) g vanilla sugar  
1 (2) tsp cinnamon  
150 (230) g softened butter

### Accessories

Baking tray or universal tray

### Method

Stir the yeast into the milk to dissolve it. Add to the flour, sugar, butter and the egg, and knead to form a smooth dough.

Shape the dough into a ball and place it in the oven compartment in an uncovered bowl. Prove the dough using the settings indicated for proving phase 1.

Peel and core the apples and slice them into wedges.

Lightly knead the dough and then roll it out on a baking tray or the universal tray. Arrange the apples evenly across the dough. Mix together the flour,

sugar, vanilla sugar and cinnamon. Then knead in the butter to create a crumble mix. Scatter over the apples.

Place the cake in the oven and prove the dough using the settings indicated for proving phase 2.

Bake the cake until golden brown.

### Settings

#### Prove dough

Proving phase 1

Special applications | Prove dough |  
Prove for 30 minutes

Proving phase 2

Oven functions: Conventional heat  
Temperature: 30 °C  
Proving time: 30 minutes

### Baking

#### Automatic programme

Cakes | Fruit streusel cake  
Programme duration:  
56 [48] (56) minutes

#### Manual

Oven functions: Conventional heat  
Temperature: 170–180 °C  
Booster: Off  
Pre-heat: Off  
Crisp function: On [Off] (On)  
Duration: 45–55 minutes  
Shelf level: 3 [2] (2)

### Tip

Instead of the apples, try using 1 kg stoned plums or cherries.

# Baked goods

---

## Melt-in-your-mouth treats

From muffins and biscuits through to choux buns, everyone will want to get their hands on these tasty morsels of fun. As they say, “good things come in small packages”. Both young and old – and short and tall – will enjoy these sweet delights.

## Biscuits

Total time required: 135 minutes

Makes 70 (2 trays)

### Ingredients

250 (380) g plain white flour

½ (1) tsp baking powder

80 (120) g caster sugar

8 (12) g vanilla sugar

3 (4) tbsp water

120 (180) g softened butter

### Accessories

Rolling pin

Biscuit cutters

2 baking trays or universal trays

### Method

Mix together the flour, baking powder, sugar and vanilla sugar. Add the rest of the ingredients and quickly knead to form a smooth dough. Chill for at least 60 minutes.

Roll out the dough to a thickness of approx. 3 mm, cut out the biscuits and place them on the baking or universal trays.

Place the biscuits in the oven compartment and bake.

### Settings

#### Automatic programme

Cookies/ Muffins | Biscuits | 1 tray / 2 trays

Programme duration 1 tray:

25 [24] (25) minutes

Programme duration 2 trays:

26 minutes

#### Manual

Oven functions: Fan plus

Temperature: 140–150 °C

Booster: Off

Pre-heat: Off

Crisp function: Off

Duration: 25–35 minutes

Shelf level 1 tray: 2 [2] (1)

Shelf level 2 trays: 1 + 3 [1 + 2] (1 + 3)

#### Tip

The quantities for the ingredients are for 2 trays. For 1 tray, halve the quantities or bake the biscuits one after the other.

# Baked goods

---

## Blueberry muffins

Total time required: 50 minutes

Makes 12

### Ingredients

225 g plain white flour  
110 g sugar  
8 g baking powder  
8 g vanilla sugar  
1 pinch of salt  
1 tbsp honey  
2 medium eggs  
100 ml buttermilk  
60 g softened butter  
250 g blueberries  
1 tbsp plain white flour

### Accessories

12 paper cake cases, Ø 5 cm  
12-cup muffin tin with cup Ø 5 cm  
Rack

### Method

Mix together the flour, sugar, baking powder, vanilla sugar and salt. Add the honey, eggs, buttermilk and butter, and stir briefly.

Mix together the blueberries and flour and carefully fold into the mixture.

Line the muffin tin with the paper cases. Distribute the mixture evenly between the muffin cases.

Place the muffin tin on the rack in the oven and bake.

### Settings

#### Automatic programme

Cookies/ Muffins | Blueberry muffins

Programme duration:

38 [41] (38) minutes

### Manual

Oven functions: Conventional heat

Temperature: 165–175 °C

Booster: Off

Pre-heat: Off

Crisp function: Off [On] (Off)

Duration: 35–45 minutes

Shelf level: 2 [1] (1)

### Tip

Fresh blueberries are best for this recipe. Use frozen blueberries straight from the freezer without defrosting them.

## Linzer biscuits

Total time required: 70 minutes

Makes 30

### For the biscuits

200 g butter

300 g plain white flour

100 g icing sugar

8 g vanilla sugar

2 medium eggs, yolks only

100 g ground almonds

Grated zest of ½ unwaxed lemon

### For the filling

200 g redcurrant jelly

### Accessories

Cling film

Baking tray or universal tray

Round biscuit cutters (in 2 sizes)

### Method

Dice the butter, add to the flour, icing sugar, vanilla sugar, egg yolk, almonds and lemon zest and knead to a form smooth dough. Wrap in cling film and chill in the fridge for 30 minutes.

Roll out the dough to a thickness of 2 mm and cut it out into circles. Make a small hole in the middle of half of the biscuits (if the biscuits are larger, make 3 holes).

Place the biscuits onto the baking tray or universal tray, place in the oven compartment and bake until pale yellow.

Allow to cool briefly after cooking. Gently heat the redcurrant jelly and spread on the biscuits without holes while they are still lukewarm. Place the biscuits with the holes on top. Dust with icing sugar.

### Settings

#### Automatic programme

Cookies/ Muffins | Linzer Augen | 1 tray / 2 trays

Programme duration 1 tray: 12 minutes

Programme duration 2 trays: 17 minutes

#### Manual

##### For 1 tray

Oven functions: Fan plus

Temperature: 160 °C

Booster: On

Pre-heat: On

Crisp function: Off

Duration: 10–15 minutes

Shelf level: 2

##### For 2 trays

Oven functions: Fan plus

Temperature: 160 °C

Booster: On

Pre-heat: On

Crisp function: Off

Duration: 13–19 minutes

Shelf level: 2 + 4 [1 + 3] (1 + 3)

#### Tip

The quantities for the ingredients are for 2 baking trays. For 1 baking tray, halve the quantities or bake the biscuits one after the other.

# Baked goods

---

## Almond macaroons

Total time required: 35 minutes

Makes 30

### Ingredients

100 g bitter almonds, blanched  
200 g sweet almonds, blanched  
600 g caster sugar  
1 pinch of salt  
4 medium eggs, whites only

### Accessories

2 baking trays or universal trays  
Baking parchment  
Piping bag with plain nozzle

### Method

Blitz the almonds in a food processor in two batches with approximately one third of the sugar.

Mix together the remaining sugar, a little salt and enough egg white to create a paste.

Line the universal tray(s) or baking tray(s) with baking parchment. Using a piping bag, pipe little balls of the mixture onto the tray.

Start the automatic programme or pre-heat the oven using the settings indicated for cooking stage 1.

Moisten the back of a spoon and use it to spread out the macaroons.

Automatic programme:

Place the almond macaroons in the oven compartment and bake until golden brown.

Manual settings:

Place the almond macaroons in the oven and bake using the settings indicated for cooking stages 2 and 3.

Allow the macaroons to cool, then remove them from the baking parchment.

### Settings

#### Automatic programme

Cookies/ Muffins | Almond macaroons |  
1 tray / 2 trays

Programme duration: 15 minutes

## Manual

### For 1 tray

Cooking stage 1

Oven functions: Conventional heat

Temperature: 200 °C

Booster: On

Pre-heat: On

Crisp function: Off

Cooking stage 2

Temperature: 180 °C

Duration: 11 minutes

Shelf level: 2 [3] (2)

Cooking stage 3

Oven functions: Fan plus

Temperature: 180 °C

Booster: Off

Pre-heat: Off

Crisp function: Off

Duration: 2–4 minutes

### For 2 trays

Cooking stage 1

Oven functions: Conventional heat

Temperature: 200 °C

Booster: On

Pre-heat: On

Crisp function: Off

Cooking stage 2

Oven functions: Fan plus

Temperature: 170 °C

Booster: Off

Pre-heat: Off

Crisp function: Off

Duration: 11 minutes

Shelf level: 1+3 [2+4] (1+3)

Cooking stage 3

Temperature: 180 °C

Duration: 2–6 minutes

## Tips

- You can replace the bitter almonds with sweet almonds and ½ a teaspoon of bitter almond essence.
- The quantities for the ingredients are for 2 trays. For 1 tray, halve the quantities or bake the biscuits one after the other.

# Baked goods

---

## Shortbread biscuits

Total time required: 50 minutes

Makes 50 (75) (2 trays)

### Ingredients

160 (240) g softened butter  
50 (80) g brown sugar  
50 (80) g icing sugar  
8 (12) g vanilla sugar  
1 (2) pinch(es) of salt  
200 (300) g plain white flour  
1 (2) medium egg(s), whites only

### Accessories

Piping bag  
Star nozzle, 9 mm  
2 baking trays or universal trays

### Method

Beat butter until creamy. Add the sugar, icing sugar, vanilla sugar and salt and beat until soft. Then fold in the flour followed by the egg white.

Put the dough in a piping bag and pipe it onto the baking tray or universal tray in strips measuring approx. 5–6 cm in length.

Place the shortbread biscuits in the oven compartment and bake until golden.

### Settings

#### Automatic programme

Cookies/ Muffins | Drop cookies | 1 tray / 2 trays

Programme duration 1 tray:

22 [21] (31) minutes

Programme duration 2 trays:

33 minutes

### Manual

#### 1 tray

Oven functions: Fan plus  
Temperature: 150–160 °C  
Booster: Off  
Pre-heat: Off  
Crisp function: Off  
Duration: 20–30 minutes  
Shelf level: 2 [2] (1)

#### 2 trays

Oven functions: Fan plus  
Temperature: 140–150 °C  
Booster: Off  
Pre-heat: Off  
Crisp function: Off  
Duration: 30–40 minutes  
Shelf level: 1 + 3 [1 + 2] (1 + 3)

### Tip

The quantities for the ingredients are for 2 trays. For 1 tray, halve the quantities or bake the biscuits one after the other.

## Vanilla biscuits

Total time required: 110 minutes

Makes 90 (130) (2 trays)

### For the dough

280 (420) g plain white flour

210 (320) g softened butter

70 (110) g caster sugar

100 (150) g ground almonds

### For dusting

70 (110) g vanilla sugar

### Accessories

2 baking trays or universal trays

### Method

Knead together the flour, butter, sugar and almonds until you have a smooth dough. Chill the dough for around 30 minutes.

Divide the dough into small pieces weighing approx. 7 g each. Roll the pieces and then shape them into cones or crescents, and place them on the baking trays or universal trays.

Place the vanilla biscuits in the oven and bake until pale yellow.

Dust with vanilla sugar while still warm.

### Settings

#### Automatic programme

Cookies/ Muffins | Vanilla biscuits | 1 tray/ 2 trays

Programme duration 1 tray: 31 minutes

Programme duration 2 trays:

35 [36] (40) minutes

### Manual

#### 1 tray

Oven functions: Fan plus

Temperature: 140–150 °C

Booster: Off

Pre-heat: Off

Crisp function: Off

Duration: 25–35 minutes

Shelf level: 2 [2] (1)

#### 2 trays

Oven functions: Fan plus

Temperature: 135–145 °C

Booster: Off

Pre-heat: Off

Crisp function: Off

Duration: 30–40 minutes

Shelf level: 1 + 3 [1 + 2] (1 + 3)

### Tip

The quantities for the ingredients are for 2 trays. For 1 tray, halve the quantities or bake the biscuits one after the other.

# Baked goods

---

## Walnut muffins

Total time required: 95 minutes

Makes 12

### Ingredients

80 g raisins

40 ml boiling water

120 g softened butter

120 g sugar

8 g vanilla sugar

2 medium eggs

140 g plain white flour

1 tsp baking powder

120 g roughly chopped walnuts

### Accessories

12-cup muffin tin with cup Ø 5 cm

Paper cases, Ø 5 cm

Rack

### Method

Drizzle the water over the raisins and leave to soak for approx. 30 minutes.

Beat butter until creamy. Gradually mix in the sugar, vanilla sugar and eggs. Sift together the flour and baking powder and mix in. Stir in the walnuts. Finally, add the water and raisins.

Line the muffin tin with the paper cases. Using 2 tablespoons, distribute the mixture evenly between the muffin cups.

Place the muffin tin on the rack in the oven and bake.

### Settings

#### Automatic programme

Cookies/ Muffins | Walnut muffins

Programme duration: 38 minutes

### Manual

Oven functions: Fan plus

Temperature: 150–160 °C

Booster: Off

Pre-heat: Off

Crisp function: Off

Duration: 30–40 minutes

Shelf level: 2 [1] (1)

## Choux buns

Total time required: 80 minutes

Makes 12 (18)

### Ingredients

250 (375) ml water

50 (75) g butter

1 (2) pinch(es) of salt

170 (225) g plain white flour

4 (6) medium eggs

1 (1½) tsp baking powder

### Accessories

Piping bag

Star nozzle, 11 mm

Baking tray or universal tray

### Manual

Oven functions: Moisture plus + Fan plus

Temperature: 160–170 °C

Booster: Off

Pre-heat: Off

Crisp function: after 15 minutes On

Number/type of bursts of steam:

1 burst of steam/automatic

Duration: 45–55 minutes

Shelf level: 2 [1] (1)

### Method

Bring the water, butter and salt to the boil in a saucepan.

Remove the pan from the hob. Tip all of the flour into the boiling liquid in one go and quickly stir until the mixture forms a ball. Return the pan to the heat and stir until a white film forms on the bottom of the pan.

Put the mixture in a bowl. Gradually mix in the eggs and beat until the mixture forms glossy peaks. Then mix in the baking powder.

Pour the mixture into a piping bag. Pipe rosettes onto the baking tray or universal tray. Bake until golden.

After baking, cut the choux buns in half horizontally and leave to cool. Remove any layers of moist pastry.

### Settings

#### Automatic programme

Cookies/ Muffins | Choux buns

Programme duration: 48 minutes

# Bread

---

## **A soft crumb wrapped in a crispy crust**

Freshly baked bread still warm from the oven is one of the easiest things to make. Whether enjoyed as a weekend breakfast treat with lashings of butter and jam or as a hearty snack after a hard day's work, bread is loved by (almost) everyone.

## Tips on preparation

To get the best results with your bread, we have compiled some of the most important tips for making dough.

The right kneading time is crucial for baking a good loaf:

- Firm doughs require a shorter kneading time than softer doughs.
- Doughs with rye flour require a shorter kneading time than doughs with wheat flour.

Bread and bread roll doughs are leavened with yeast or sourdough. To give the microorganisms inside the yeast optimum working conditions and for the dough to rise as much as possible, there needs to be a warm, moist environment. We therefore recommend using a special automatic programme to prove your yeast-based dough.

Introducing moisture during baking has 2 positive effects:

- A skin forms on the dough very slowly during baking. This means the bread has longer to rise.
- The gelatinisation of starch on the surface of the bread produces a shiny, crunchy crust.

## Preparation of yeast-based dough for bread

1. Make and prove the yeast-based dough according to the recipe. You can also find helpful videos about shaping bread and bread rolls in the Miele@mobile app.
2. The consistency of the dough determines whether or not you need to dust your work surface with flour during preparation: if the dough sticks to your fingers when you touch it, you should always lightly flour your work surface.
3. Pull the dough up slightly from the outside and press down firmly in the middle. Repeat this process at least six times. The dough should sit with the dough seam facing down.
4. The dough should be left to rest for at least 1 minute before it is made into a loaf or bread rolls.

# Bread

---

## Preparation of free-form loaves and baguettes

Free-form loaves are loaves that are not baked in a tin.

1. Position the dough with the seam facing upwards and press in along the middle of the dough with the side of your hand.
2. Fold one side to the middle and press firmly. Repeat the process on the other side. Then turn the dough over and mould it into the shape you want.
3. There are 2 ways to create cracking:
  - If you want consistent cracking, the dough pieces need to be placed with the dough seam facing downwards and then scored on the smooth top.
  - If you want rustic cracking, the dough pieces need to be placed on their smooth side so that the dough seam faces up.

## What to do if...

### ...the dough is too firm:

Add some liquid as the moisture content in flour fluctuates, meaning more or less liquid may be required to get a smooth dough.

### ...the dough is too moist:

Extend the kneading time, but do not exceed 10 minutes.

If the longer kneading time is not sufficient, gradually and rapidly knead in some flour.

### ...the bread “collapses”:

One option is to reduce the proving time. If the proving time is too long, too many gases are produced for the dough to hold. The dough has been over-proved and loses its shape.

Use cold liquid ingredients where possible as the dough warms up during the kneading process. If the dough temperature is too high, the fermentation process is accelerated.

Bake the bread at a higher temperature for the first 10 minutes.

**...the bread has compact, moist spots (water streaks):**

Bake the bread at a lower temperature for the first 10 minutes.

The baking environment is too moist, meaning no moisture can be released from the dough.

Extend the proving stages to pre-bind more moisture in the dough structure.

**...the bread cracks when it shouldn't:**

The environment should always be moist during the proving stage and the first baking stage. The moisture produces condensation on the surface of the dough, which produces a ductile skin.

The dough piece is not scored deeply or often enough.

**...the bread has a dull surface:**

There needs to be sufficient moisture during the proving stage and the first baking stage. The moisture causes the starch to gelatinise on the dough surface.

**...the bread is not crisp enough:**

Provide more moisture during the first baking stage to ensure that the bread does not become dry.

A longer baking time will release more moisture from the dough, which will form a thicker crust.

Bake the bread at a higher temperature for the first 10 minutes.

# Bread

---

## Baguettes

Total time required: 120 minutes

Makes two 10-slice loaves

### Ingredients

21 g fresh yeast

270 ml cold water

500 g strong white flour

2 tsp salt

½ tsp sugar

1 tbsp softened butter

### Accessories

Baking tray or universal tray

### Method

Stir the yeast into the water to dissolve it. Add to the flour, salt, sugar and butter and knead for 6–7 minutes until you have a smooth dough.

Shape the dough into a ball and place it in the oven compartment in an uncovered bowl. Prove the dough using the settings indicated for proving phase 1.

Divide the dough in half. Shape each half into a baguette measuring 35 cm in length. Place the baguettes across the baking tray or universal tray and score the dough several times diagonally to a depth of 1 cm.

Automatic programme:

Start the automatic programme and place the baguettes in the oven.

Manual settings:

Prove the dough using the settings indicated for proving phase 2. Then bake.

### Settings

#### Prove dough

Proving phase 1

Special applications | Prove dough | Prove for 30 minutes

Proving phase 2

Special applications | Prove dough | Prove for 15 minutes

### Baking

#### Automatic programme

Bread | Baguettes

Programme duration: 69 minutes

#### Manual

Oven functions: Moisture plus + Fan plus

Temperature: 190–200 °C

Booster: Off

Pre-heat: Off

Crisp function: On after 15 minutes

Number/type of bursts of steam:

1 burst of steam/manual, immediately after placing the food in the oven

Duration: 30–40 minutes

Shelf level: 2 [1] (1)

## Swiss farmhouse bread

Total time required: 160 minutes

Makes one 15-slice loaf

### Ingredients

25 g fresh yeast

300 ml lukewarm milk

350 g strong white flour

150 g rye flour

1 tsp salt

### For dusting

1 tbsp plain white flour

### Accessories

Baking tray or universal tray

### Method

Stir the yeast into the milk to dissolve it. Add to the flour and salt and knead to form a soft, smooth dough.

Shape the dough into a ball, place it in a bowl and cover with a damp cloth.

Leave to prove at room temperature for 60 minutes.

Shape the dough into a round loaf and place on the universal tray. Dust with flour. Score the top of the dough lengthways and crosswise to a depth of about 1 cm.

Leave to prove at room temperature for 30 minutes.

Start the automatic programme or pre-heat the oven.

Place in the oven compartment and bake.

### Settings

#### Automatic programme

Bread | Swiss farmhouse bread

Programme duration: 48 minutes

#### Manual

Oven functions: Moisture plus + Fan plus

Temperature: 180–210°C

Booster: On

Pre-heat: On

Crisp function: Off

Number/type of bursts of steam:

2 bursts of steam/manual, first after 6 minutes, second after another 6 minutes

Duration: 40 minutes

Shelf level: 2 [1] (2)

# Bread

---

## Spelt bread

Total time required: 130 minutes

Makes one 20-slice loaf

### Ingredients

120 g carrots

42 g fresh yeast

210 ml cold water

300 g wholemeal spelt flour

200 g white spelt flour

2 tsp salt

100 g whole almonds

### Accessories

Baking tray or universal tray

### Method

Finely grate the carrots.

Stir the yeast into the water to dissolve it. Add to the flour, salt and carrots and knead for 4–5 minutes until you have a smooth dough.

Add the almonds and knead for another 2–3 minutes.

Shape the dough into a ball and place it in the oven compartment in an uncovered bowl. Prove the dough using the settings indicated for proving phase 1.

Lightly knead the dough and shape into a loaf measuring approx. 25 cm long. Place the loaf across the baking tray or universal tray. Score the loaf diagonally several times to a depth of ½ cm.

**Automatic programme:**  
Start the automatic programme and place the bread dough inside the oven.

**Manual settings:**

Prove the dough using the settings indicated for proving phase 2. Then bake the bread.

### Settings

#### Prove dough

Proving phase 1

Special applications | Prove dough |  
Prove for 30 minutes

Proving phase 2

Special applications | Prove dough |  
Prove for 15 minutes

### Baking

#### Automatic programme

Bread | Spelt bread

Programme duration: 72 minutes

#### Manual

Oven functions: Moisture plus + Fan plus

Temperature: 180–190 °C

Booster: On

Pre-heat: Off

Crisp function: Off

Number/type of bursts of steam:

1 burst of steam/manual, immediately after placing the food in the oven

Duration: 50–60 minutes

Shelf level: 2 [1] (1)

### Tip

You can use walnuts or pumpkin seeds instead of almonds.

## Flatbread

Total time required: 100 minutes  
Makes 1 flatbread with 8 servings

### For the dough

42 g fresh yeast  
200 ml cold water  
375 g strong white flour  
1½ tsp salt  
2 tbsp olive oil

### For glazing

Water  
½ tbsp olive oil

### For sprinkling

½ tbsp nigella seeds

### Accessories

Baking tray or universal tray

### Method

Stir the yeast into the water to dissolve it. Add to the flour, salt and oil and knead for 6–7 minutes until you have a smooth dough.

Shape the dough into a ball and place it in the oven compartment in an uncovered bowl. Prove the dough using the settings indicated for proving phase 1.

Roll the dough out flat to a diameter of approx. 25 cm and place it on the baking tray or universal tray.

Brush with a thin layer of water. Sprinkle on the nigella seeds and gently press them into the flatbread dough. Brush with olive oil.

Automatic programme:  
Start the automatic programme and place the bread dough inside the oven.

Manual settings:

Prove the dough using the settings indicated for proving phase 2. Then bake the bread.

### Settings

#### Prove dough

Proving phase 1  
Special applications | Prove dough |  
Prove for 30 minutes

Proving phase 2  
At room temperature  
Proving time: 10 minutes

### Baking

#### Automatic programme

Bread | Flat bread  
Programme duration: 44 minutes

#### Manual

Oven functions: Moisture plus +  
Conventional  
Temperature: 200–210°C  
Booster: On  
Pre-heat: Off  
Crisp function: Off  
Number/type of bursts of steam:  
1 burst of steam/manual, immediately  
after placing the food in the oven  
Duration: 25–35 minutes  
Shelf level: 2 [1] (1)

### Tip

Try kneading the following into the dough: 50 g roasted onions and 2 tsp Herbes de Provence or 50 g chopped black olives, 1 tbsp chopped pine nuts and 1 tsp rosemary.

# Bread

---

## Plaited loaf

Total time required: 140 minutes

Makes one 16-slice loaf

### For the dough

42 g fresh yeast

150 ml lukewarm milk, 3.5 % fat

500 g strong white flour

70 g sugar

100 g butter

1 medium egg

1 tsp lemon zest

2 pinches of salt

### For glazing

2 tbsp milk, 3.5 % fat

### For sprinkling

20 g flaked almonds

20 g sugar crystals

### Accessories

Baking tray or universal tray

### Method

Stir the yeast into the milk to dissolve it. Add to the flour, sugar, butter, egg, lemon zest and salt and knead for 6–7 minutes until you have a smooth dough.

Shape the dough into a ball and place it in the oven compartment in an uncovered bowl. Prove the dough using the settings indicated for proving phase 1.

Divide the dough into 3 strands, each weighing 300 g and measuring 40 cm in length. Then plait the 3 strands and place on the baking tray or universal tray.

Brush the plaited dough with milk and then sprinkle over the almonds and sugar crystals.

Automatic programme:

Start the automatic programme and then place the plaited dough in the oven.

Manual settings:

Prove the dough using the settings indicated for proving phase 2. Then bake the loaf.

### Settings

#### Prove dough

Proving phase 1

Special applications | Prove dough | Prove for 30 minutes

Proving phase 2

Special applications | Prove dough | Prove for 15 minutes

### Baking

#### Automatic programme

Bread | Plaited loaf

Programme duration:

55 [50] (55) minutes

#### Manual

Oven functions: Moisture plus + Fan plus

Temperature: 160–170°C

Booster: Off

Pre-heat: Off

Crisp function: Off

Number/type of bursts of steam:

1 burst of steam/manual, immediately after placing the food in the oven

Duration: 30–40 minutes

Shelf level: 2 [1] (1)

### Tip

Knead 100 g of raisins into the dough if you wish.

## Nut bread

Total time required: 200 minutes

Makes one 25-slice loaf

### For the dough

175 g coarsely ground rye

500 g wholemeal flour

14 g dried yeast

2 tsp salt

75 g molasses

500 ml lukewarm buttermilk

50 g halved walnuts

100 g whole hazelnuts

### For the tin

1 tbsp butter

### Accessories

Loaf tin, 30 cm long

Rack

Cooling rack

### Method

Mix together the coarse rye, flour, dried yeast and salt. Add the molasses and butter milk and knead for 4–5 minutes until you have a smooth dough. Add the nuts and knead for another 2–3 minutes.

Place the dough in the oven compartment in an uncovered bowl. Prove the dough using the indicated settings.

Grease the loaf tin. Lightly knead the soft dough on a floured surface, shape into a roll measuring approx. 28 cm in length and place in the loaf tin.

Place the on the rack in the oven and bake.

Once baked, remove the bread from the loaf tin, leave to cool on a cooling rack and store in an airtight container. The bread tastes best if you leave it to rest for a day before slicing.

### Settings

#### Prove dough

Special applications | Prove dough | Prove for 45 minutes

Then leave it to prove in the switched off oven for another 15 minutes.

### Baking

#### Automatic programme

Bread | Nut bread

Programme duration: 105 minutes

#### Manual

Oven functions: Moisture plus + Fan plus

Temperature: 150–160 °C

Booster: Off

Pre-heat: Off

Crisp function: Off

Number/type of bursts of steam:

2 bursts of steam/time-controlled, first after 3 minutes, second after 10 minutes

Duration: 95–105 minutes

Shelf level: 2 [1] (1)

# Bread

---

## Mixed rye bread

Total time required: 140 minutes

Makes one 20-slice loaf

### For the dough

21 g fresh yeast

1 tbsp barley malt extract

350 ml cold water

350 g rye flour

170 g strong white flour

2½ tsp salt

75 g liquid sourdough

### For the tin

1 tbsp butter

### Accessories

Loaf tin, 25 cm long

Rack

### Method

Stir the yeast and barley malt extract into the water to dissolve it. Add to the flour, salt and sourdough and knead for 3–4 minutes to form a smooth dough.

Place the dough in the oven compartment in an uncovered bowl. Prove the dough using the settings indicated for proving phase 1.

Grease the loaf tin. Lightly work the dough with a rubber spatula and transfer it to the loaf tin. Level the top with a wet rubber spatula.

Prove the dough using the settings indicated for proving phase 2.

Start the automatic programme or pre-heat the oven.

Then bake the bread.

## Settings

### Prove dough

Proving phase 1

Special applications | Prove dough |

Prove for 45 minutes

Proving phase 2

Oven functions: Conventional heat

Temperature: 30 °C

Proving time: 15 minutes

## Baking

### Automatic programme

Bread | Mixed rye bread

Programme duration:

69 [67] (69) minutes

### Manual

Oven functions: Moisture plus +

Conventional

Temperature: 220 °C, 190 °C after

15 minutes

Booster: On

Pre-heat: On

Crisp function: On after 15 minutes

Number/type of bursts of steam:

2 bursts of steam/time-controlled, first

after 1 minute,

second after 7 minutes

Duration: 55–65 minutes

Shelf level: 2 [1] (1)

## Tip

You can also use honey or molasses instead of barley malt extract.

# Bread

---

## Seeded loaf

Total time required: 140 minutes

Makes one 25-slice loaf

### For the dough

42 g fresh yeast  
420 ml cold water  
400 g rye flour  
200 g strong white flour  
3 tsp salt  
1 tsp honey  
150 g liquid sourdough  
20 g linseeds  
50 g sunflower seeds  
50 g sesame seeds

### For sprinkling

1 tbsp sesame seeds  
1 tbsp linseeds  
1 tbsp sunflower seeds

### For glazing

Water

### For the tin

1 tbsp butter

### Accessories

Loaf tin, 30 cm long  
Rack

### Method

Stir the yeast into the water to dissolve it. Add to the flour, salt, honey and sourdough and knead for 3–4 minutes until you have a soft dough.

Add the linseeds, sunflower seeds and sesame seeds and knead for another 1–2 minutes.

Place the dough in the oven compartment in an uncovered bowl. Prove the dough using the settings indicated for proving phase 1.

Grease the loaf tin. Lightly work the dough with a rubber spatula and transfer it to the loaf tin. Level the top with a wet rubber spatula, brush with water and sprinkle on the mixed seeds.

Prove the dough using the settings indicated for proving phase 2.

Start the automatic programme or pre-heat the oven.

Then bake the bread.

## Settings

### Prove dough

Proving phase 1

Special applications | Prove dough |

Prove for 30 minutes

Proving phase 2

Oven functions: Conventional heat

Temperature: 30 °C

Proving time: 10–15 minutes

## Baking

### Automatic programme

Bread | Seeded loaf

Programme duration:

69 [66] (69) minutes

### Manual

Oven functions: Moisture plus +

Conventional

Temperature: 220°C, nach 15 Minuten

190 °C

Booster: On

Pre-heat: On

Crisp function: On after 15 minutes

Number/type of bursts of steam:

2 bursts of steam/time-controlled,

first after 1 minute, second after

7 minutes

Duration: 55–65 minutes

Shelf level: 2 [1] (1)

# Bread

---

## Tiger bread

Total time required: 125 minutes

Makes one 15-slice loaf

### For the bread

15 g fresh yeast

300 ml lukewarm water

500 g strong white flour

2 tsp salt

20 g butter

### For the topping

100 g rice flour

125 ml water

1 tsp sugar

5 g dried yeast

### Accessories

Loaf tin, 25 cm long

Rack

### Method

Stir the yeast into the water to dissolve it. Add to the flour, salt and butter, and knead to form a smooth dough.

Shape the dough into a ball and leave it to prove in a covered bowl at room temperature for 30 minutes.

In the meantime, mix together the ingredients for the topping, cover and leave to prove at room temperature for 30 minutes.

Then roll out the dough into a 30 cm square. Fold in 2 sides so they meet in the middle. Starting with one of the folded sides, roll up the dough and place in a loaf tin. Cover and leave to prove for another 30 minutes.

Place the rack in the oven. Start the automatic programme or pre-heat the oven.

Brush the bread with the topping.

Manual settings:

Place the bread dough in the oven compartment and bake using the settings indicated for cooking stages 1 and 2.

Automatic programme:

Place the bread dough in the oven and bake.

### Settings

#### Automatic programme

Bread | Tiger bread

Programme duration: 35 minutes

#### Manual

Cooking stage 1

Oven functions: Moisture plus + Fan plus

Temperature: 220 °C

Booster: On

Pre-heat: On

Crisp function: Off

Number/type of bursts of steam:

2 bursts of steam/manual: first immediately after placing the food in the oven,

second after 5 minutes

Duration: 20 minutes

Shelf level: 2 [1] (2)

Cooking stage 2

Oven functions: Fan plus

Temperature: 175–200 °C

Booster: Off

Pre-heat: Off

Crisp function: Off

Duration: 10–15 minutes

## White loaf (in loaf tin)

Total time required: 140 minutes

Makes one 25-slice loaf

### For the dough

21 g fresh yeast

290 ml cold water

500 g strong white flour

2 tsp salt

½ tsp sugar

1 tbsp butter

### For the tin

1 tbsp butter

### Accessories

Loaf tin, 30 cm long

Rack

### Method

Stir the yeast into the water to dissolve it. Add to the flour, salt, sugar and butter and knead for 6–7 minutes until you have a smooth dough.

Shape the dough into a ball and place it in the oven compartment in an uncovered bowl. Prove the dough using the settings indicated for proving phase 1.

Grease the loaf tin. Lightly knead the dough, shape into a roll measuring approx. 28 cm in length and place in the loaf tin. Score lengthways to a depth of approx. 1 cm.

Automatic programme:

Start the automatic programme and then place the bread dough in the oven.

Manual settings:

Prove the dough using the settings indicated for proving phase 2. Then bake.

### Settings

#### Prove dough

Proving phase 1

Special applications | Prove dough | Prove for 30 minutes

Proving phase 2

Special applications | Prove dough | Prove for 15 minutes

### Baking

#### Automatic programme

Bread | White bread | Baking tin

Programme duration: 87 minutes

#### Manual

Oven functions: Moisture plus + Conventional

Temperature: 190–200 °C

Booster: On

Pre-heat: Off

Crisp function: Off

Number/type of bursts of steam:

1 burst of steam/manual, immediately after placing the food in the oven

Duration: 55–65 minutes

Shelf level: 2 [1] (1)

# Bread

---

## White loaf (free form)

Total time required: 140 minutes

Makes one 20-slice loaf

### Ingredients

21 g fresh yeast

260 ml cold water

500 g strong white flour

2 tsp salt

½ tsp sugar

1 tbsp butter

### Accessories

Baking tray or universal tray

### Method

Stir the yeast into the water to dissolve it. Add to the flour, salt, sugar and butter and knead for 6–7 minutes until you have a smooth dough.

Shape the dough into a ball and place it in the oven compartment in an uncovered bowl. Prove the dough using the settings indicated for proving phase 1.

Lightly knead the dough and shape into a loaf measuring approx. 25 cm long. Place the loaf across the baking tray or universal tray. Score several times to a depth of 1 cm.

Automatic programme:

Start the automatic programme and place the bread dough inside the oven.

Manual settings:

Prove the dough using the settings indicated for proving phase 2. Then bake the bread.

### Settings

#### Prove dough

Proving phase 1

Special applications | Prove dough | Prove for 45 minutes

Proving phase 2

Special applications | Prove dough | Prove for 15 minutes

### Baking

#### Automatic programme

Bread | White bread | On tray

Programme duration: 64 minutes

#### Manual

Oven functions: Moisture plus + Fan plus

Temperature: 190–200 °C

Booster: On

Pre-heat: Off

Crisp function: On after 15 minutes

Number/type of bursts of steam:  
2 bursts of steam/time-controlled,  
first after 1 minute, second after  
8 minutes

Duration: 30–40 minutes

Shelf level: 2 [1] (1)

## Dark mixed wheatgrain bread

Total time required: 140 minutes

Makes one 20-slice loaf

### For the dough

350 g wholemeal flour

150 g rye flour

7 g dried yeast

2½ tsp salt

300 ml cold water

1 tsp honey

50 ml oil

### For sprinkling

1 tbsp wholemeal flour

### For the tin

1 tbsp butter

### Accessories

Loaf tin, 25 cm long

Rack

### Method

Mix together the flour, dried yeast and salt. Add the water, honey and oil and knead for 6–7 minutes until you have a smooth dough.

Shape the dough into a ball and place it in the oven compartment in an uncovered bowl. Prove the dough using the settings indicated for proving phase 1.

Grease the loaf tin. Lightly knead the dough, shape into a roll measuring approx. 23 cm in length and place in the loaf tin. Score it several times lengthways, then crosswise to a depth of 1 cm, creating a pattern of small squares. Dust with flour.

Automatic programme:

Start the automatic programme and place the bread dough inside the oven.

Manual settings:

Prove the dough using the settings indicated for proving phase 2. Place the bread in the oven compartment and bake.

### Settings

#### Prove dough

Proving phase 1

Special applications | Prove dough |

Prove for 45 minutes

Proving phase 2

Special applications | Prove dough |

Prove for 15 minutes

### Baking

#### Automatic programme

Bread | Dark mixed grain bread

Programme duration: 92 minutes

#### Manual

Oven functions: Moisture plus +  
Conventional

Temperature: 190–200 °C

Booster: On

Pre-heat: Off

Crisp function: On after 15 minutes

Number/type of bursts of steam:

2 bursts of steam/time-controlled, first  
after 1 minute, second after 8 minutes

Duration: 55–65 minutes

Shelf level: 2 [1] (1)

# Bread

---

## Ginger loaf

Total time required: 120 minutes

Makes one 15-slice loaf

### For the bread

25 g fresh yeast

100 ml lukewarm milk, 3.5 % fat

500 g strong white flour

1 pinch of salt

90 g butter

2 medium eggs

3 tbsp ginger syrup

40 g preserved stem ginger, chopped

1 tsp cinnamon

100 g sugar crystals

### For the tin

1 tbsp butter

1 tbsp sugar

### Accessories

Loaf tin, 25 cm long

Rack

### Method

Stir the yeast into the milk to dissolve it. Add to the flour, salt, butter, eggs and ginger syrup, and knead to a smooth dough. Shape the dough into a ball and leave it to prove in a bowl for 60 minutes at room temperature.

Grease the tin and sprinkle with sugar.

Knead the chopped ginger, cinnamon and sugar crystals into the dough. Shape the dough into a loaf, place it in the loaf tin and leave to prove for a further 15 minutes.

Place the rack in the oven. Start the automatic programme or pre-heat the oven using the settings indicated for cooking stage 1.

Sprinkle the sugar over the bread dough.

Automatic programme:

Place the bread dough in the oven and bake until golden brown.

Manual settings:

Place the bread dough in the oven compartment and bake until golden brown using the settings indicated for cooking stages 2 and 3.

## Settings

### Automatic programme

Bread | Ginger loaf

Programme duration: 40 minutes

### Manual

Cooking stage 1

Oven functions: Moisture plus + Fan plus

Temperature: 200 °C

Booster: On

Pre-heat: On

Crisp function: Off

Shelf level: 2 [1] (2)

Cooking stage 2

Temperature: 190 °C

Number/type of bursts of steam:

1 burst of steam/manual: immediately after placing the food in the oven

Duration: 5 minutes

Cooking stage 3

Oven functions: Fan plus

Temperature: 160–170 °C

Booster: Off

Pre-heat: Off

Crisp function: Off

Duration: 35 minutes

# Bread rolls

---

## Multigrain rolls

Total time required: 140 minutes

Makes 8

### For the dough

10 g wheat bran  
25 g chia seeds  
25 g sunflower seeds  
½ tsp salt  
240 ml lukewarm water  
150 g white spelt flour  
150 g wholemeal flour  
1 pinch of sugar  
1 tsp salt  
10 g fresh yeast  
1 tsp oil

### For glazing

Water

### For dusting

1 tbsp linseeds  
1 tbsp sesame seeds  
1 tbsp poppy seeds

### Accessories

Baking tray or universal tray

### Method

Mix together the wheat bran, chia seeds, sunflower seeds, salt and water and leave to soak for at least 90 minutes.

Mix together the flour, sugar and salt. Crumble the yeast on top. Add oil and the seeds including the water and knead for 9–10 minutes to form a soft dough.

Shape the dough into a ball and place it in the oven compartment in an uncovered bowl. Prove the dough using the settings indicated for proving phase 1.

Mix together the linseeds, sesame seeds and poppy seeds.

Use the soft dough to shape 8 bread rolls weighing 75 g each. Brush the tops with a little water, roll in the mixed seeds and place on the baking tray or universal tray.

Automatic programme:

Start the automatic programme and then place the bread rolls in the oven

Manual settings:

Prove the dough using the settings indicated for proving phase 2. Then bake the rolls.

## Settings

### Prove dough

Proving phase 1

Special applications | Prove dough |

Prove for 45 minutes

Proving phase 2

Special applications | Prove dough |

Prove for 30 minutes

## Baking

### Automatic programme

Rolls | Multigrain rolls

Programme duration: 77 minutes

### Manual

Oven functions: Moisture plus + Fan  
plus

Temperature: 170–180 °C

Booster: Off

Pre-heat: Off

Crisp function: On after 15 minutes

Number/type of bursts of steam:

1 burst of steam/manual, immediately  
after placing the food in the oven

Duration: 30–40 minutes

Shelf level: 2 [1] (1)

# Bread rolls

---

## Rye bread rolls

Total time required: 140 minutes + 12–15 hours to prove the starter dough

Makes 8

### For the dough

250 g wholemeal rye flour

75 g liquid sourdough

7 g dried yeast

300 ml cold water

300 g strong white flour

2 tsp salt

### For sprinkling

2 tbs wholemeal rye flour

### Accessories

Baking tray or universal tray

### Method

Mix the wholemeal rye flour with the sourdough, dried yeast and water to form a paste. Place in a bowl and cover it with a cloth. Leave to prove at room temperature for 12–15 hours.

Add the flour and salt and knead for 6–7 minutes until you have a smooth dough.

Shape the dough into a ball and place it in the oven compartment in an uncovered bowl. Prove the dough using the settings indicated for proving phase 1.

Divide the dough into 8 portions weighing 110 g each and place on a floured surface.

Pull the dough of each portion up slightly from the outside and press down firmly in the middle. Repeat this process several times.

Shape the dough portions into balls with your palms.

Place the dough pieces onto the baking tray or universal tray with the seam facing up and dust generously with flour.

Prove the dough using the settings indicated for proving phase 2.

Start the automatic programme or pre-heat the oven. Then bake the rolls.

## Settings

### Prove dough

Proving phase 1

Special applications | Prove dough |

Prove for 45 minutes

Then leave it to prove in the switched off oven for another 15 minutes.

Proving phase 2

Oven functions: Conventional heat

Temperature: 30 °C

Proving time: 30 minutes

## Baking

### Automatic programme

Rolls | Rye rolls

Programme duration: approx.

45 [42] (45) minutes

## Manual

Oven functions: Moisture plus + Fan plus

Temperature: 190–200 °C

Booster: On

Pre-heat: On

Crisp function: On after 15 minutes

Number/type of bursts of steam:

1 burst of steam/manual, immediately after placing the food in the oven

Duration: 25–35 minutes

Shelf level: 2 [2] (1)

# Bread rolls

---

## White rolls

Total time required: 140 minutes

Makes 8

### For the dough

10 g fresh yeast

200 ml cold water

340 g strong white flour

1½ tsp salt

1 tsp sugar

1 tsp butter

### Accessories

Baking tray or universal tray

### Method

Stir the yeast into the water to dissolve it. Add to the flour, salt, sugar and butter and knead for 6–7 minutes until you have a smooth dough.

Shape the dough into a ball and place it in the oven compartment in an uncovered bowl. Prove the dough using the settings indicated for proving phase 1.

Use the dough to shape 8 bread rolls weighing 70 g each and place them on the baking tray or universal tray. Score in a cross shape approx. ½ cm deep.

Automatic programme:

Start the automatic programme and then place the bread rolls in the oven.

Manual settings:

Prove the dough using the settings indicated for proving phase 2. Then bake the rolls.

### Settings

#### Prove dough

Proving phase 1

Special applications | Prove dough | Prove for 45 minutes

Proving phase 2

Special applications | Prove dough | Prove for 30 minutes

### Baking

#### Automatic programme

Rolls | White rolls

Programme duration: 72 minutes

#### Manual

Oven functions: Moisture plus + Fan plus

Temperature: 170–180 °C

Booster: Off

Pre-heat: Off

Crisp function: On after 15 minutes

Number/type of bursts of steam:

1 burst of steam/manual, immediately after placing the food in the oven

Duration: 30–40 minutes

Shelf level: 2 [1] (1)

### Tip

Shape the bread rolls, brush with water and dip in poppy seeds or sesame seeds. Alternatively, sprinkle them with coarse salt and whole caraway seeds.

### **The tastiest treats in the world!**

Pizzas, tarts and pies are great favourites for all occasions – as a satisfying family supper, as part of a buffet or as a snack when playing a board game or watching TV. Whether it is the combination of mild flavoured pastry and a hearty filling, or the imaginative twist on traditional dishes, these savoury recipes will whet your appetite and inspire you to try other variations.

# Pizza and Co.

---

## Pizza (yeast-based dough)

Total time required: 90 minutes

4 (6) servings (Baking tray), 2 servings (Round baking tray)

### For the dough (Baking tray)

30 (42) g fresh yeast  
170 (250) ml lukewarm water  
300 (450) g strong white flour  
1 (1½) tsp sugar  
1 (1½) tsp salt  
½ (1) tsp dried rubbed thyme  
1 (1½) tsp dried rubbed oregano  
1 (1½) tbsp oil

### For the topping (Baking tray)

2 (3) onions  
1 (1½) clove(s) of garlic  
400 (600) g tinned tomatoes, skinned and chopped  
2 (3) tbsp tomato purée  
1 (1½) tsp sugar  
1 (1½) tsp dried rubbed oregano  
1 (1½) bay leaf  
1 (1½) tsp salt  
Pepper  
125 (190) g mozzarella  
125 (190) g grated gouda

### For frying

1 tbsp olive oil

### For the dough (Round baking tray)

10 g fresh yeast  
70 ml lukewarm water  
130 g plain white flour  
½ tsp sugar  
½ tsp salt  
Dried rubbed thyme  
½ tsp dried rubbed oregano  
1 tsp oil

### For the topping (Round baking tray)

1 onion  
½ clove of garlic  
200 g tinned tomatoes, skinned and chopped  
1 tbsp tomato purée  
½ tsp sugar  
½ tsp dried rubbed oregano  
½ bay leaf  
½ tsp salt  
Pepper  
60 g mozzarella  
60 g grated gouda

### For frying

1 tsp olive oil

### Accessories

Rolling pin  
Baking tray or universal tray or round baking tray and rack

### Method

Stir the yeast into the water to dissolve it. Add to the flour, sugar, salt, thyme, oregano and oil and knead for 6–7 minutes until you have a smooth dough.

Shape the dough into a ball, place it in a bowl and cover with a damp cloth. Leave to prove at room temperature for 20 minutes.

To make the topping, finely dice the onion(s) and garlic. Heat the oil in a pan. Sweat the onion(s) and garlic until translucent. Add the tomatoes, tomato purée, sugar, oregano, bay leaf and salt.

Bring the sauce to the boil and simmer on a gentle heat for a few minutes.

Remove the bay leaf, season with salt and pepper to taste. Slice the mozzarella.

Roll the dough out onto the baking tray or universal tray. If using the round baking tray, roll out the dough and place it in the tray. Leave to prove at room temperature for 10 minutes.

Start the automatic programme or pre-heat the oven using the settings indicated for cooking stage 1.

Spread the sauce over the dough. Leave a gap of approx. 1 cm all the way round the edge. Top with the mozzarella and sprinkle on the gouda.

Manual settings:

Adjust settings as indicated for cooking stage 2.

Place the pizza in the oven compartment and bake.

## Settings

### Automatic programme

Pizza & Quiche | Pizza | Yeast dough |

Baking tray /

Round baking tray

Programme duration Baking tray:

42 [45] (46) minutes

Programme duration Round baking tray:

33 [29] (33) minutes

## Manual

### Baking tray

Oven functions: Conventional heat

Temperature: 210–220 °C

Booster: Off

Pre-heat: On

Crisp function: On

Duration: 25–35 minutes

Shelf level: 2 [1] (2)

### Round baking tray

Oven functions: Conventional heat

Temperature: 210–220 °C

Booster: On

Pre-heat: On

Crisp function: On

Duration: 20–30 minutes

Shelf level: 1

# Pizza and Co.

---

## Pizza (quark dough)

Total time required: 60 minutes

4 (6) servings (tray), 2 servings (round baking tray)

### For the dough (Baking tray)

120 (180) g quark,  
20 % fat in dry matter  
4 (6) tbsp milk, 3.5 % fat  
4 (6) tbsp oil  
2 (3) medium eggs, yolks only  
1 (1½) tsp salt  
1½ (2½) tsp baking powder  
250 (380) g plain white flour

### For the topping (Baking tray)

2 (3) onions  
1 (1½) clove(s) of garlic  
400 (600) g tinned tomatoes, skinned  
and chopped  
2 (3) tbsp tomato purée  
1 (1½) tsp sugar  
1 (1½) tsp oregano  
1 (1½) bay leaf  
1 (1½) tsp salt  
Pepper  
125 (190) g mozzarella  
125 (190) g grated gouda

### For frying

1 (1½) tbsp olive oil

### For the dough (Round baking tray)

50 g quark, 20 % fat in dry matter  
2 tbsp milk, 3.5 % fat  
2 tbsp oil  
½ tsp salt  
1 medium egg, yolk only  
1 tsp baking powder  
110 g plain white flour

### For the topping (Round baking tray)

1 onion  
½ clove of garlic  
200 g tinned tomatoes, skinned and  
chopped  
1 tbsp tomato purée  
½ tsp sugar  
½ tsp oregano  
½ bay leaf  
½ tsp salt  
Pepper  
60 g mozzarella  
60 g grated gouda

### For frying

1 tsp olive oil

### Accessories

Rolling pin  
Baking tray or universal tray or round  
baking tray and rack

### Method

To make the topping, finely dice the onion(s) and garlic. Heat the oil in a pan. Sweat the onion(s) and garlic until translucent. Add the tomatoes, tomato purée, sugar, oregano, bay leaf and salt.

Bring the sauce to the boil and simmer on a gentle heat for a few minutes.

Remove the bay leaf. Season with salt and pepper to taste. Slice the mozzarella.

To make the dough, start by mixing together the quark, milk, oil, egg yolk and salt. Sift together the flour and baking powder. Mix half the amount into the dough. Then knead in the rest.

Roll the dough out onto the baking tray or universal tray. If using the round baking tray, roll out the dough and place it in the tray.

Start the automatic programme or pre-heat the oven.

Spread the sauce over the dough. Leave a gap of approx. 1 cm all the way round the edge. Top with the mozzarella and sprinkle on the gouda.

Place the pizza in the oven compartment and bake.

## Settings

### Automatic programme

Pizza & Quiche | Pizza | Quark dough |

Baking tray / Round baking tray

Programme duration Baking tray:

38 [33] (40) minutes

Programme duration Round baking tray:

33 [27] (32) minutes

## Manual

### Baking tray

Oven functions: Conventional heat

Temperature: 190–200 °C

Booster: On

Pre-heat: On

Crisp function: On

Duration: 30–40 minutes

Shelf level: 3 [1] (2)

### Round baking tray

Oven functions: Conventional heat

Temperature: 190–200 °C

Booster: On

Pre-heat: On

Crisp function: On

Duration: 20–30 minutes

Shelf level: 3 [2] (2)

# Pizza and Co.

---

## Savoury tart (puff pastry)

Total time required: 70 minutes

Serves 8

### For the pastry

230 g puff pastry

### For the vegetable filling

500 g diced vegetables (e.g. leeks, carrots, broccoli, spinach)

1 tsp butter

50 g mature cheese, grated

### For the cheese filling

350 g mature cheese, grated

### For the topping

2 medium eggs

200 ml double cream

Salt

Pepper

Nutmeg

### Accessories

Round baking tray, Ø 27 cm

Rack

### Method

Line the baking tray with the pastry.

Method for the vegetable tart:

Sauté vegetables in butter and leave to cool. Arrange over the pastry and scatter cheese on top.

Method for the cheese tart:

Scatter cheese on top.

Insert the rack. Start the automatic programme or pre-heat the oven.

To make the filling, mix together the eggs and cream. Season with salt, pepper and nutmeg to taste. Pour the topping over the tart and bake until golden brown.

### Settings

#### Automatic programme

Pizza & Quiche | Savoury flan | Puff pastry

Programme duration: 36 minutes

#### Manual

Oven functions: Conventional heat

Temperature: 220–230 °C

Booster: On

Pre-heat: On

Crisp function: On

Duration: 36–42 minutes

Shelf level: 1

#### Tip

Mature cheeses such as gruyere, sbrinz or emmental can all be used with this recipe

## Savoury tart (shortcrust pastry)

Total time required: 100 minutes

Serves 8

### For the shortcrust pastry

80 g butter

200 g plain white flour

65 ml water

¼ tsp salt

### For the vegetable filling

500 g diced vegetables (e.g. leeks, carrots, broccoli, spinach)

1 tsp butter

50 g mature cheese, grated

### For the cheese filling

260 g grated mature cheese (e.g. gruyere, sbrinz and emmental)

### For the topping

2 medium eggs

200 ml double cream

Salt

Pepper

Nutmeg

### Accessories

Round baking tray, Ø 27 cm

Rack

### Method

Dice the butter and add to the flour, salt and water and rapidly knead to form a dough. Chill for 30 minutes.

Line the baking tray with the dough.

Method for the vegetable tart:

Sauté vegetables in butter and leave to cool. Arrange over the pastry and scatter cheese on top.

Method for the cheese tart:

Scatter cheese on top.

Insert the rack. Start the automatic programme or pre-heat the oven.

To make the filling, mix together the eggs and cream. Season with salt, pepper and nutmeg to taste. Pour the topping over the base.

Place in the oven and bake until golden brown.

### Settings

#### Automatic programme

Pizza & Quiche | Savoury flan |

Shortcrust pastry

Programme duration: 43 minutes

#### Manual

Oven functions: Conventional heat

Temperature: 220–240 °C

Booster: On

Pre-heat: On

Crisp function: On

Duration: 36–45 minutes

Shelf level: 1

#### Tip

Alternatively, use 230 g of ready-made shortcrust pastry.

# Meat

---

## Let's have meat!

Meat such as beef, lamb and game are healthy components of anyone's diet, and add a wealth of variety and enjoyment to it. Poultry is particularly recommended for our well-being. Meat can be prepared and cooked in a range of different ways, and by using diverse seasonings and serving it up with interesting sauces and side dishes, it can constantly be presented in new guises, uniting cultures – both exotic and traditional – through its versatility.

## Tips on preparation

### Roasting

The high heat during roasting forms a brown outer layer. The remnants from this layer are what give the food the typical roasted taste.

- Coat the poultry or meat with oil and season to taste before putting it in the oven.
- If an automatic programme or recipe recommends using an oven dish, the Miele Gourmet oven dish has been optimally designed for these programmes. When using ovenproof glass, ceramic or stainless steel roasting dishes, you might need to reduce the quantity of liquid being added.
- Some programmes require you to add extra liquid part way through the cooking time, and sometimes you may need to remove the lid. This will be indicated in the display. For manual settings, the step is noted in the recipe.
- Always place poultry in the oven with the breast side facing upwards. Brush the skin with lightly salted water 10 minutes before the end of the cooking time. This makes the skin nice and crispy.

### Low temperature cooking

Low temperature cooking requires the meat to be seared in a pan and then cooked at a temperature of less than 100 °C. This method is particularly suitable for lean cuts of meat to keep them succulent and tender.

- Use lean meat which has been correctly hung and trimmed. Bones should be removed before cooking.
- Do not cover meat during cooking.
- The meat is at an ideal temperature for eating immediately after cooking. Serve on pre-heated plates with a hot sauce or gravy to keep the meat warm.

# Meat

---

## Food probe

You don't have to be a professional to have perfectly cooked meat. The core temperature of a piece of meat is a good indicator of how cooked it is. Lots of Miele ovens come with a food probe that helps you to get perfect cooking results.

- Make sure that the metal tip is inserted into the middle of the thickest part of the meat.
- If the piece of meat is too small or thin, you can place a piece of raw potato over the exposed area of the food probe.
- Do not allow the tip of the food probe to come into contact with bones, sinews or fatty layers.
- With poultry, insert the food probe deep into the thickest part of the breast meat at the front.
- When using the wireless food probe, the handle should point diagonally upwards where possible.
- A rough cooking duration is indicated in the display at the start of cooking and this time is then adjusted towards the end.
- If you are cooking several pieces of meat at the same time, insert the food probe into the largest piece of meat.

## Stuffed duck

Total time required: 135 minutes

Serves 4

### For the duck

1 duck (2 kg), ready to cook

1 tsp salt

Pepper

1 tsp thyme

### For the filling

2 diced oranges

1 diced apple

1 diced onion

½ tsp salt

Pepper

1 tsp dried rubbed thyme

1 bay leaf

### For the sauce

475 ml chicken stock

400 ml water

125 ml orange juice

1 tsp cornflour

1 tbsp cold water

Salt

Pepper

### Accessories

Gourmet oven dish

Food probe

4 skewers

### Method

Season the duck with the salt, pepper and thyme.

To make the stuffing, mix together the diced orange, apple and onion. Season with the salt, pepper, thyme and bay leaf.

Fill the duck with the stuffing and secure with skewers.

Place the duck breast side up in the Gourmet oven dish. Insert the food probe. Place the Gourmet oven dish in the oven .

Automatic programme:

Start the automatic programme. Mix the chicken stock and water. When prompted to do so in the display, pour in ¼ l of liquid every 40 minutes.

Manual settings:

Cook using the indicated settings. Mix the chicken stock and water. Pour over ¼ l of liquid every 40 minutes.

At the end of the cooking duration, remove the duck from the oven. Skim off any fat and pour the juices into a saucepan. Add the rest of the chicken stock and the orange juice.

Stir the cornflour into the water and then add it to the sauce to aid thickening. Then bring to the boil. Season with salt and pepper to taste.

### Settings

#### Automatic programme

Meat | Poultry | Duck

Programme duration:

approx. 115 minutes

#### Manual

Oven functions: Auto roast

Temperature: 180–190 °C

Core temperature: 95 °C

Booster: On

Pre-heat: Off

Crisp function: Off

Duration: 100–120 minutes

Shelf level: 2 [2] (1)

# Meat

---

## Stuffed goose

Total time required: 200 minutes

Serves 6

### Ingredients

2 tsp caraway seeds, ground  
1 tbsp marjoram  
Salt  
Pepper  
1 goose  
(3½ kg) without giblets, ready to cook  
2 apples  
2 unwaxed oranges  
3 spring onions  
500 ml goose stock

### Accessories

Cocktail sticks  
Gourmet oven dish  
Rack

### Method

Mix the caraway seeds, marjoram, salt and pepper together and use the mixture to season the goose. Leave the spice mix to soak into the meat for around 15 minutes.

In the meantime, wash the apples and oranges thoroughly, and cut into large cubes without peeling them. Stuff the goose with the fruit. Use cocktail sticks to close the cavity if you want to.

Start the automatic programme or pre-heat the oven.

Fill the Gourmet oven dish with approximately a finger's height of hot water. Place the goose breast side down in the Gourmet oven dish. Place spring onions around the goose.

Automatic programme:

Place the Gourmet oven dish in the oven compartment and roast.

Manual settings:

Place the Gourmet oven dish in the oven and roast using the settings indicated for cooking stages 1, 2 and 3.

Turn the goose halfway through cooking. Pour the fat from the Gourmet oven dish into the saucepan.

After cooking, remove the goose from the Gourmet oven dish and allow to rest briefly. The orange and apple stuffing is only intended to add flavour and not to eat.

Remove the spring onions. Deglaze the meat juice with goose stock and leave to reduce on the hob.

Serve the goose with the sauce.

## Settings

### Automatic programme

Meat | Poultry | Goose | stuffed

Programme duration: 180 minutes

### Manual

Cooking stage 1

Oven functions: Moisture plus + Fan plus

Temperature: 220 °C

Booster: On

Pre-heat: On

Crisp function: Off

Number/type of bursts of steam:

3 bursts of steam/manual: first immediately after placing the food in the oven, second after 5 minutes, third after another 10 minutes

Duration: 25 minutes

Shelf level: 2 [1] (1)

Cooking stage 2

Oven functions: Fan plus

Temperature: 160 °C

Booster: Off

Pre-heat: Off

Crisp function: Off

Duration: 75 minutes

Cooking stage 3

Oven functions: Fan plus

Temperature: 140 °C

Duration: 80 minutes

## Tip

To reheat the goose once carved, place on a baking tray and reheat under a pre-heated grill at 240 °C for 5 minutes.

# Meat

---

## Goose (without stuffing)

Total time required: 200 minutes

Serves 4

### Ingredients

1 goose (4.5 kg), ready to cook

2 tbsp salt

500 ml vegetable stock

### Accessories

Gourmet oven dish

Food probe

### Method

Rub the goose inside and out with salt.

Place the goose breast side up in the Gourmet oven dish. Insert the food probe. Place the Gourmet oven dish in the oven compartment and roast.

After 30 minutes, pour over the vegetable stock.

After another 30 minutes, baste with the juices.

### Settings

#### Automatic programme

Meat | Poultry | Goose | unstuffed

Programme duration: approx.

170 minutes

#### Manual

Oven functions: Auto roast

Temperature: 160–170 °C

Core temperature: 95 °C

Booster: On

Pre-heat: Off

Crisp function: Off

Duration: 180–200 minutes

Shelf level: 2 [2] (1)

## Chicken

Total time required: 75 minutes

Serves 2

### Ingredients

1 chicken (1.2 kg), ready to cook

2 tbsp oil

1½ tsp salt

2 tsp sweet paprika

1 tsp curry powder

### Accessories

Rack

Ovenproof dish, 22 cm x 29 cm

Food probe

Kitchen twine

### Method

Mix the oil with the salt, paprika and curry powder; then coat the chicken with it.

Tie the legs together with kitchen twine and put the chicken breast side up in the ovenproof dish. Insert the food probe.

Place the ovenproof dish on the rack and slide it into the oven compartment with the legs of the bird pointing towards the door. Roast the chicken.

### Settings

#### Automatic programme

Meat | Poultry | Chicken | Whole

Programme duration: approx.

60 minutes

#### Manual

Oven functions: Auto roast

Temperature: 170–180 °C

Core temperature: 85 °C

Booster: On

Pre-heat: Off

Crisp function: Off

Duration: approx. 55–65 minutes

Shelf level: 2 [1] (1)

# Meat

---

## Chicken thighs

Total time required: 75 minutes

Serves 4

### For the chicken thighs

2 tbsp oil

1½ tsp salt

Pepper

1 tsp paprika

4 chicken thighs (200 g each), ready to cook

### For the vegetables

4 tbsp oil

1 red pepper, roughly chopped into equal sized pieces

1 yellow pepper, roughly chopped into equal sized pieces

1 aubergine, roughly chopped into equal sized pieces

1 courgette, roughly chopped into equal sized pieces

2 red onions, roughly diced

2 cloves of garlic, lightly crushed

2 sprigs of fresh rosemary

4 sprigs of fresh thyme

200 g cherry tomatoes | halved

200 ml tomato passata

100 ml vegetable stock

½ tsp salt

Pepper

1 tsp sugar

Hot paprika

### Accessories

Universal tray

Gourmet oven dish

### Method

Mix together the oil, salt, pepper and paprika; then coat the chicken thighs with it. Place the chicken thighs onto the universal tray, place in the oven compartment and roast.

To cook the vegetables, heat the oil in the Gourmet oven dish on the hob on a medium to high heat. Sauté the peppers and aubergine, stirring frequently. Add the courgette, onions and garlic and fry on a medium heat, stirring frequently.

Tie together the rosemary and thyme. Add the herbs, halved tomatoes, tomato passata and stock; briefly bring to the boil on a medium to high heat. Simmer on a medium heat for approx. 15 minutes, stirring several times.

Season with salt, pepper, sugar and paprika to taste. Serve the chicken thighs on top of the vegetables.

## Settings

### Automatic programme

Meat | Poultry | Chicken | Chicken  
thighs

Programme duration: 33 minutes.

### Manual

Oven functions: Moisture plus + Auto  
roast

Temperature: 190–200 °C

Booster: On

Pre-heat: Off

Crisp function: Off

Number/type of bursts of steam:

1 burst of steam/time-controlled, after  
15 minutes

Duration: 30–40 minutes

Shelf level: 2 [2] (1)

# Meat

---

## Stuffed turkey

Total time required: 230 minutes

Serves 8

### For the filling

125 g raisins  
2 tbsp water  
3 tbsp oil  
3 diced onions  
100 g parboiled rice  
150 ml water  
½ tsp salt  
100 g pistachio nuts, shelled  
Salt  
Pepper  
Curry powder  
Garam masala

### For the turkey

1 turkey (5 kg), ready to cook  
1 tbsp salt  
2 tsp pepper  
500 ml chicken stock

### For the sauce

250 ml water  
150 ml crème fraîche  
2 tbsp cornflour  
2 tbsp cold water  
Salt  
Pepper

### Accessories

Gourmet oven dish  
Food probe  
6 cocktail sticks  
Kitchen twine

### Method

To make the stuffing, drizzle the fortified water over the raisins. Sauté the onions in oil. Add the rice, sauté briefly and deglaze with the water. Add the salt. Briefly bring to the boil and allow the rice to swell on a gentle heat. Add the pistachio nuts and raisins and mix them in. Season with salt, pepper, curry powder and garam masala to taste.

Season the turkey with salt and pepper. Fill the turkey with the stuffing and seal it with the cocktail sticks and kitchen twine. If necessary, loosely tie the legs together. Place the turkey breast side up in the Gourmet oven dish and insert the food probe.

Place the Gourmet oven dish in the oven compartment and roast.

After 30 minutes, pour over ¼ of the chicken stock, pour over another ¼ after another 30 minutes. Then baste with the stock every 30 minutes.

Remove the turkey from the oven and dilute the juices with water. Add the crème fraîche. Stir the cornflour into the cold water and then add it to the sauce to aid thickening. Then bring to the boil. Season with salt and pepper to taste.

## **Settings**

### **Automatic programme**

Meat | Poultry | Turkey | Whole

Programme duration: approx.  
180 minutes

### **Manual**

Oven functions: Auto roast

Temperature: 150–160 °C

Core temperature: 85 °C

Booster: On

Pre-heat: Off

Crisp function: Off

Duration: approx. 160–180 minutes

Shelf level: 2 [2] (1)

# Meat

---

## Turkey thigh

Total time required: 125 minutes

Serves 4

### For the turkey thigh

2 tbsp oil

1 tsp salt

Pepper

1 turkey thigh (1.2 kg), ready to cook

500 ml water

### For the sauce

1 tin apricot halves (280 g), drained

150 ml water

200 ml double cream

200 g mango chutney

Salt

Pepper

### Accessories

Gourmet oven dish

Food probe

### Method

Mix together the oil, salt and pepper and then coat the turkey thigh with the mixture. Place the turkey thigh skin side up in the Gourmet oven dish and insert the food probe. Place the Gourmet oven dish in the oven compartment and roast.

Pour on water after 45 minutes and continue cooking. Meanwhile, cut the apricot halves into pieces.

Remove the turkey thigh from the oven. To make the sauce, dilute the juices with water. Add the cream and chutney and briefly bring to the boil.

Add the apricot pieces to the sauce. Season with salt and pepper to taste. Bring back to the boil.

## Settings

### Automatic programme

Meat | Poultry | Turkey | Turkey

drumsticks

Programme duration: approx.

76 minutes

### Manual

Oven functions: Moisture plus + Auto  
roast

Temperature: 190–200 °C

Core temperature: 85 °C

Booster: On

Pre-heat: Off

Crisp function: Off

Number/type of bursts of steam:

2 bursts of steam/time-controlled, first  
after 10 minutes, second after another  
25 minutes

Duration: approx. 70–80 minutes

Shelf level: 2 [2] (1)

# Meat

---

## Roast fillet of veal

Total time required: 125 minutes

Serves 4

### For the fillet of veal

2 tbsp oil

1 tsp salt

Pepper

1 kg fillet of veal, ready to cook

### For frying

2 tbsp oil

### For the sauce

30 g dried morels

300 ml boiling water

1 onion

30 g butter

180 ml double cream

3 tbsp cold water

1 tbsp cornflour

Salt

Pepper

Sugar

### Accessories

Universal tray

Food probe

Fine sieve

### Method

Start the automatic programme or pre-heat the oven.

Heat the oil in a pan and sear the veal fillet all over (approx. 1 minute per side).

Mix together the oil, salt and pepper; then coat the veal fillet with it.

Place the veal fillet on the universal tray and insert the food probe. Place the universal tray in the oven compartment and roast the veal fillet.

To make the sauce, pour the boiling water on the morels and leave to soak for 15 minutes.

Dice the onion. Drain the morels with a sieve, keeping the water for later. Squeeze the water out of the morels and dice finely.

Sweat the onions in butter for 5 minutes. Add the morels and sweat for another 5 minutes.

Add the water from the mushrooms and the cream and bring to the boil. Stir the cornflour into the water and then add it to the sauce to aid thickening. Briefly bring back to the boil. Season with salt, pepper and sugar to taste.

## Settings

### Automatic programme

Meat | Veal | Fillet of veal | Roast

Programme duration:

approx. 43 minutes

### Manual

Oven functions: Conventional heat

Temperature: 160–170 °C

Core temperature: 45 °C (pink),  
57 °C (medium), 75 °C (well-done)

Booster: On

Pre-heat: On

Crisp function: Off

Duration: approx. 30–40 minutes (pink),  
40–50 minutes (medium), 50–  
60 minutes (well-done)

Shelf level: 2 [1] (1)

### Tip

Porcini mushrooms can be used  
instead of dried morels.

# Meat

---

## Fillet of veal (low temperature cooking)

Total time required: 100 minutes

Serves 4

### For the fillet of veal

2 tbsp oil

1 tsp salt

Pepper

1 kg fillet of veal, ready to cook

### For frying

2 tbsp oil

### Accessories

Rack

Universal tray

Food probe

### Method

Put the rack on the universal tray and place in the oven. Start the automatic programme or special application.

Mix together the oil, salt and pepper; then coat the veal fillet with it.

Heat the oil in a pan and sear the veal fillet all over (approx. 1 minute per side).

Remove the veal fillet from the pan and insert the food probe.

Place the veal fillet on the rack and cook.

### Settings

#### Automatic programme

Meat | Veal | Fillet of veal | Low temp. cooking

Programme duration: approx. 92 minutes

#### Manual

Special applications | Low temp. cooking

Temperature: 80–100 °C

Core temperature: 45 °C (pink), 57 °C (medium), 66 °C (well-done)

Duration: approx. 40–60 minutes (pink), 70–80 minutes (medium), 90–120 minutes (well-done)

Shelf level: 2 [1] (1)

## Veal knuckle

Total time required: 150 minutes

Serves 4

### For the veal knuckle

2 tbsp oil

1½ tsp salt

½ tsp pepper

1 veal knuckle (1.5 kg), ready to cook

1 onion

1 clove

2 carrots

80 g celery

1 tbsp tomato purée

800 ml veal stock

200 ml water

### For the sauce

75 ml double cream

1½ tbsp cornflour

2 tbsp cold water

Salt

Pepper

### Accessories

Gourmet oven dish

Food probe

Hand-held blender

Fine sieve

### Method

Mix together the oil, salt and pepper; then coat the veal knuckle with it.

Quarter the onion and stick the clove into it. Peel and roughly dice the celery and carrots.

Place the vegetables, tomato purée and veal knuckle in the Gourmet oven dish. Insert the food probe. Place the Gourmet oven dish in the oven compartment and roast.

After 50 minutes, pour over a half of the stock and half of the water. After 30 minutes, pour over the other half of the stock and water.

Remove the veal knuckle and vegetables from the oven. Take the clove out of the onion.

Place the vegetables and juices in a saucepan and blend to make a purée. Pass the purée through a sieve, pour in the cream and bring to the boil.

Stir the cornflour into the water and then add it to the sauce to aid thickening. Briefly bring back to the boil. Season with salt and pepper to taste.

### Settings

#### Automatic programme

Meat | Veal | Veal knuckle

Programme duration:  
approx. 120 minutes

#### Manual

Oven functions: Conventional heat  
Temperature: 190–200 °C  
Core temperature: 76 °C  
Booster: On  
Pre-heat: Off  
Crisp function: Off  
Duration: approx. 120–130 minutes  
Shelf level: 2 [2] (1)

# Meat

---

## Roast saddle of veal

Total time required: 60 minutes

Serves 4

### For the saddle of veal

2 tbsp oil

1 tsp salt

Pepper

1 kg saddle of veal, ready to cook

### For frying

2 tbsp oil

### Accessories

Food probe

Universal tray

### Method

Start the automatic programme or pre-heat the oven.

Heat the oil in a pan and sear the saddle of veal all over (approx. 1 minute per side).

Remove the saddle of veal from the pan. Mix together the oil, salt and pepper; then coat the saddle of veal with it.

Insert the food probe. Place the saddle of veal in the oven compartment on the universal tray and roast.

### Settings

#### Automatic programme

Meat Veal | Loin of veal | Roast

Programme duration: approx.

50 minutes

#### Manual

Oven functions: Conventional heat

Temperature: 180–190 °C

Core temperature: 45 °C (pink),

57 °C (medium), 75 °C (well-done)

Booster: On

Pre-heat: On

Crisp function: Off

Duration: approx. 30–40 minutes (pink),

40–50 minutes (medium), 50–

60 minutes (well-done)

Shelf level: 2 [1] (1)

## Saddle of veal (low temperature cooking)

Total time required: 150 minutes

Serves 4

### For the saddle of veal

2 tbsp oil

1 tsp salt

Pepper

1 kg saddle of veal, ready to cook

### For frying

2 tbsp oil

### Accessories

Rack

Universal tray

Food probe

### Method

Put the rack on the universal tray and place in the oven. Start the automatic programme or special application.

Mix together the oil, salt and pepper; then coat the saddle of veal with it.

Heat the oil in a pan and sear the saddle of veal all over (approx. 1 minute per side).

Remove the saddle of veal from the pan and insert the food probe.

Place the saddle of veal on the rack and cook.

### Settings

#### Automatic programme

Meat | Veal | Loin of veal | Low temp. cooking

Programme duration:  
approx. 134 minutes

#### Manual

Special applications | Low temp. cooking

Temperature: 80–100 °C

Core temperature: 45 °C (pink),  
57 °C (medium), 66 °C (well-done)

Duration: approx. 70–90 minutes (pink),  
100–130 minutes (medium), 130–  
150 minutes (well-done)

Shelf level: 2 [1] (1)

# Meat

---

## Braised veal

Total time required: 150 minutes

Serves 4

### For the joint

2 tbsp oil

1 tsp salt

Pepper

1 kg veal (leg or flank), ready to cook

2 carrots, roughly diced

2 tomatoes, roughly diced

2 roughly diced onions

2 marrow bones (veal or beef)

500 ml veal stock

500 ml water

### For the sauce

250 ml double cream

1 tsp cornflour

1 tbsp cold water

Salt

Pepper

### For frying

2 tbsp oil

### Accessories

Gourmet oven dish with lid

Fine sieve

Hand-held blender

### Method

Start the automatic programme or pre-heat the oven.

Heat the oil in the Gourmet oven dish and sear the veal all over (approx. 1 minute per side).

Remove the veal. Mix together the oil, salt and pepper; then coat the veal with it.

Sauté the vegetables in the Gourmet oven dish. Add the marrow bones and veal meat. Pour over half of the water and half of the veal stock. Place the Gourmet oven dish in the oven. Cover and cook.

After 95 minutes, remove the lid and after a further 5 minutes, pour on the remaining veal stock and water and finish cooking.

Remove the veal, bones and half of the vegetables. Place the remaining vegetables and juices in a saucepan and blend to make a purée. Pass the purée through a sieve, add the cream and bring to the boil.

Stir the cornflour into the water and then add it to the sauce to aid thickening. Briefly bring back to the boil. Season with salt and pepper to taste.

### Settings

#### Automatic programme

Meat | Veal | Braised veal

Programme duration:

127 [125] (127) minutes

#### Manual

Oven functions: Fan plus

Temperature: 160–170 °C

Booster: On

Pre-heat: On

Crisp function: Off

Duration: 120–130 minutes

Shelf level: 2 [2] (1)

## Osso buco

Total time required: 130 minutes

Serves 6

### For the osso buco

2 tbsp oil  
 1 diced tomato  
 1 finely chopped onion  
 80 g diced carrots  
 80 g diced celery  
 50 g leeks, sliced into rings  
 4 finely chopped cloves of garlic  
 1 tbsp tomato purée  
 6 slices of veal knuckle  
 (approx. 250 g each)  
 Salt  
 Freshly ground pepper  
 2 tbsp plain white flour  
 50 g butter  
 1l beef stock  
 1 tbsp gravy paste  
 30 g rosemary  
 30 g sage  
 30 g thyme

### For sprinkling

1 tbsp parsley, chopped  
 Grated zest of 1 unwaxed lemon

### Accessories

Gourmet oven dish with lid

### Method

Start the automatic programme or pre-heat the oven using the settings indicated for cooking stage 1.

Pour the oil into the Gourmet oven dish. Add the vegetables, garlic and tomato purée.

Put the Gourmet oven dish in the oven and braise using the settings indicated for cooking stage 2.

Season the veal knuckle with salt and pepper and turn in flour. Heat the butter in a pan and sear the veal knuckle on both sides for 3–4 minutes.

Place the veal knuckle, beef stock, gravy paste and herbs on top of the vegetables in the Gourmet oven dish. Leave to braise with the lid on using the settings for cooking stage 3.

Serve the veal knuckle with the sauce and garnish with lemon zest and parsley.

### Settings

#### Automatic programme

Meat | Veal | Osso buco

Programme duration: 110 minutes

#### Manual

Cooking stage 1

Oven functions: Fan plus

Temperature: 200 °C

Booster: On

Pre-heat: On

Crisp function: Off

Cooking stage 2

Temperature: 180 °C

Duration: 10 minutes

Shelf level: 2 [1] (1)

Cooking stage 3

Temperature: 180 °C

Duration: 90 minutes

# Meat

---

## Rack of lamb with vegetables

Total time required: 60 minutes

Serves 4

### Ingredients

2 tsp rosemary  
2 crushed cloves of garlic  
30 g oil  
80 g Dijon mustard  
2 tbsp cumin  
1 tsp honey  
¼ tsp salt  
Freshly ground pepper  
2 racks of lamb (approx. 8 cutlets on each), ready to cook  
2 carrots  
1 sweet potato  
4 new potatoes  
2 small beetroots  
2 onions  
2 tbsp oil  
Salt  
Pepper

### Accessories

Rack or grilling and roasting insert  
Universal tray  
Aluminium foil

### Method

Mix together the rosemary, garlic, oil, Dijon mustard, cumin, honey, salt and pepper and spread over the racks of lamb. Place the racks of lamb on the rack or the grilling and roasting insert and place on the universal tray in the oven.

Peel the carrots and sweet potato and dice. Halve the new potatoes. Cut the onions and beetroots into wedges.

Mix the vegetables with the oil, place on the universal tray and season with salt. Place the universal tray with the vegetables under the meat and cook using the settings for cooking stage 1.

Remove the racks of lamb from the oven. Place the vegetables on a higher shelf level and cook using the settings indicated for cooking stage 2.

Once the racks of lamb are cooked, wrap them in aluminium foil and leave to rest for 10 minutes. Then carve and serve with the vegetables.

## Settings

### Automatic programme

Meat | Lamb | Rack of lamb with  
vegetables

Programme duration: 34 minutes

### Manual

Cooking stage 1

Oven functions: Moisture plus + Fan  
plus

Temperature: 190 °C

Booster: On

Pre-heat: On

Crisp function: Off

Number/type of bursts of steam:  
2 bursts of steam/manual, first once the  
temperature has been reached, second  
after another 10 minutes

Duration: 24 minutes

Shelf level: 3 (rack of lamb) +  
2 (vegetables) [3 (rack of lamb) +  
1 (vegetables)] (2)

Cooking stage 2

Oven functions: Fan grill

Temperature: 190 °C

Duration: 10 minutes

Shelf level: 2

# Meat

---

## Leg of lamb

Total time required: 140 minutes

Serves 6

### For the leg of lamb

3 tbsp oil

1½ tsp salt

½ tsp pepper

2 crushed cloves of garlic

3 tsp Herbes de Provence

1 leg of lamb (1.5 kg), ready to cook

### For pouring over

500 ml vegetable stock

### For the sauce

500 ml water

50 ml crème fraîche

3 tbsp cold water

3 tsp cornflour

Salt

Pepper

### Accessories

Gourmet oven dish with lid

Food probe

### Method

Mix the oil with salt, pepper, garlic and herbs and coat the leg of lamb with the mixture.

Place the leg of lamb in the Gourmet oven dish and insert the food probe. Place the Gourmet oven dish in the oven. Cover and cook.

After 30 minutes, take off the lid. Pour over the vegetable stock, and continue cooking.

Remove the leg of lamb from the oven, dilute the juices with water. Add the crème fraîche and briefly bring to the boil. Stir the cornflour into the water and then add it to the sauce to aid thickening. Briefly bring back to the boil. Season with salt and pepper to taste.

## **Settings**

### **Automatic programme**

Meat | Lamb | Leg of lamb

Programme duration: approx.

130 minutes

### **Manual**

Oven functions: Conventional heat

Temperature: 170–180 °C

Core temperature: 76 °C

Booster: Off

Pre-heat: Off

Crisp function: Off

Duration: approx. 100–120 minutes

Shelf level: 2 [2] (1)

# Meat

---

## Roast saddle of lamb

Total time required: 30 minutes

Serves 4

### For the saddle of lamb

2 tbsp oil

1 tsp salt

Pepper

3 loins of lamb (300 g each), ready to cook

### For frying

1 tbsp oil

### Accessories

Universal tray

Food probe

### Method

Start the automatic programme or pre-heat the oven.

Heat the oil in a pan and sear the loins of lamb all over (approx. 1 minute per side).

Mix the oil, salt and pepper; then coat the loins of lamb with the mixture.

Place the loins of lamb on the universal tray and insert the food probe. Place the universal tray in the oven compartment. Cook.

### Settings

#### Automatic programme

Meat | Lamb | Saddle of lamb | Roast

Programme duration: approx.

23 minutes

### Manual

Oven functions: Conventional heat

Temperature: 180–190 °C

Core temperature: 53 °C (pink),

65 °C (medium), 80 °C (well-done)

Booster: On

Pre-heat: On

Crisp function: Off

Duration: approx. 10–15 minutes (pink),

15–20 minutes (medium), 20–

25 minutes (well-done)

Shelf level: 2 [1] (1)

## Saddle of lamb (low temperature cooking)

Total time required: 90 minutes

Serves 4

### For the saddle of lamb

2 tbsp oil

1 tsp salt

Pepper

3 loins of lamb (300 g each), ready to cook

### For frying

1 tbsp oil

### Accessories

Rack

Universal tray

Food probe

### Method

Put the rack on the universal tray and place in the oven. Start the automatic programme or special application.

Mix the oil with the salt and pepper and coat the loins of lamb with the mixture.

Heat the oil in a pan and sear the loins of lamb all over (approx. 1 minute per side).

Remove the loins of lamb from the pan and insert the food probe.

Place the loins of lamb on the rack and cook.

### Settings

#### Automatic programme

Meat | Lamb | Saddle of lamb | Low temp. cooking

Programme duration: approx.

75 minutes

### Manual

Special applications | Low temp. cooking

Temperature: 95–105 °C

Core temperature: 53 °C (pink), 65 °C (medium), 68 °C (well-done)

Duration: approx. 25–35 minutes (pink), 65–75 minutes (medium), 80–90 minutes (well-done)

Shelf level: 2 [1] (1)

# Meat

---

## Beef hash

Total time required: 250 minutes

Serves 8

### Ingredients

30 g butter

3 tbsp oil

1.2 kg diced beef, ready to cook

Salt

Pepper

500 g onions, finely diced

2 bay leaves

4 cloves

1 tbsp brown sugar

2 tbsp plain white flour

1.2 l beef stock

### Accessories

Gourmet oven dish with lid

### Method

Heat the butter in a pan. As soon as it begins to bubble, add a dash of oil and heat.

Season the beef with salt and pepper and sear it on all sides.

Add the onions, bay leaves, cloves and sugar and cook for a further 3 minutes.

Dust the beef with flour and fry for a further 2–3 minutes.

Add the beef stock, stirring constantly until you have a smooth sauce.

Put the beef into the Gourmet oven dish.

Start the automatic programme or pre-heat the oven.

Automatic programme:

Place the Gourmet oven dish in the oven compartment and roast.

Manual settings:

Place the Gourmet oven dish in the oven and cook using the settings indicated for cooking stages 1 and 2.

Before serving, season again with salt and pepper.

### Settings

#### Automatic programme

Meat | Beef | Beef hash

Programme duration: 210 minutes

#### Manual

Cooking stage 1

Oven functions: Fan plus

Temperature: 180 °C

Booster: On

Pre-heat: On

Crisp function: Off

Duration: 45 minutes

Shelf level: 2

Cooking stage 2

Temperature: 150 °C

Duration: 165 minutes

## Roast fillet of beef

Total time required: 55 minutes

Serves 4

### For the fillet of beef

2 tbsp oil

1 tsp salt

Pepper

1 kg beef fillet, ready to cook

### For frying

2 tbsp oil

### Accessories

Universal tray

Food probe

### Method

Start the automatic programme or pre-heat the oven.

Heat the oil in a pan and sear the beef fillet all over (approx. 1 minute per side).

Mix together the oil, salt and pepper; then coat the beef fillet with the mixture.

Place the fillet of beef on the universal tray, insert the food probe and place in the oven compartment. Cook the beef fillet.

### Settings

#### Automatic programme

Meat | Beef | Fillet of beef | Roast

Programme duration:

approx. 43 minutes

#### Manual

Oven functions: Conventional heat

Temperature: 180–190 °C

Core temperature: 45 °C (rare), 54 °C (medium), 75 °C (well-done)

Booster: On

Pre-heat: On

Crisp function: Off

Duration: approx. 20–30 minutes (rare),

35–45 minutes (medium), 50–

60 minutes (well-done)

Shelf level: 2 [1] (1)

# Meat

---

## Fillet of beef (low temperature cooking)

Total time required: 95 minutes

Serves 4

### For the fillet of beef

2 tbsp oil

1 tsp salt

Pepper

1 kg beef fillet, ready to cook

### For frying

2 tbsp oil

### Accessories

Rack

Universal tray

Food probe

### Method

Put the rack on the universal tray and place in the oven. Start the automatic programme or special application.

Mix together the oil, salt and pepper; then coat the beef fillet with the mixture.

Heat the oil in a pan and sear the beef fillet all over (approx. 1 minute per side).

Remove the beef fillet from the pan and insert the food probe.

Place the beef fillet on the rack and cook.

### Settings

#### Automatic programme

Meat | Beef | Fillet of beef | Low temp. cooking

Programme duration: approx. 85 minutes

#### Manual

Special applications | Low temp. cooking

Temperature: 80–100 °C

Core temperature: 45 °C (rare), 57 °C (medium), 66 °C (well-done)

Duration: approx. 50–70 minutes (rare), 70–90 minutes (medium), 100–120 minutes (well-done)

Shelf level: 2 [1] (1)

## Braised beef

Total time required: 145 minutes

Serves 4

### For the joint

2 tbsp oil

1 tsp salt

Pepper

1 kg beef (suitable for braising), ready to cook

200 g carrots, roughly diced

2 roughly diced onions

50 g celery, roughly diced

1 bay leaf

500 ml beef stock

500 ml water

### For frying

2 tbsp oil

### For the sauce

250 ml water

125 ml crème fraîche

1 tsp cornflour

1 tbsp cold water

Salt

Pepper

### Accessories

Gourmet oven dish with lid

Sieve

Hand-held blender

### Method

Start the automatic programme or pre-heat the oven.

Heat the oil in the Gourmet oven dish. Sear the beef all over (approx. 1 minute per side).

Remove the beef from the dish. Mix together the oil, salt and pepper and coat the beef with the mixture.

Sauté the vegetables in the Gourmet oven dish. Add the beef and bay leaf. Pour over half of the water and half of the beef stock.

Place the Gourmet oven dish in the oven compartment, cover it and roast.

After 105 minutes, pour over the remaining beef stock and water and after a further 10 minutes, take off the lid.

To make the sauce, remove the beef and bay leaf. Add water as required. Place the vegetables and juices in a saucepan and blend to make a purée. Pass the purée through a sieve, add the crème fraîche and bring to the boil.

Stir the cornflour into the water and then add it to the sauce to aid thickening. Briefly bring back to the boil. Season with salt and pepper to taste.

### Settings

#### Automatic programme

Meat | Beef | Braised beef

Programme duration: 131 minutes

#### Manual

Oven functions: Fan plus

Temperature: 150–160 °C

Booster: On

Pre-heat: On

Crisp function: Off

Duration: 120–130 minutes

Shelf level: 2 [2] (1)

# Meat

---

## Roast sirloin joint

Total time required: 80 minutes

Serves 4

### For the sirloin

2 tbsp oil

1 tsp salt

Pepper

1 kg sirloin joint, ready to cook

### For frying

2 tbsp oil

### For the remoulade

150 g yoghurt, 3.5 % fat

150 g mayonnaise

2 pickled gherkins

2 tbsp capers

1 tbsp parsley

2 shallots

1 tbsp chives

½ tsp lemon juice

Salt

Sugar

### Accessories

Universal tray

Food probe

### Method

Start the automatic programme or pre-heat the oven.

Heat the oil in a pan. Sear the sirloin joint on all sides (approx. 1 minute per side).

Remove the sirloin joint from the pan. Mix together the oil, salt and pepper; then coat the beef joint with it.

Place the sirloin joint on the universal tray and insert the food probe.

Place the universal tray in the oven compartment and roast the sirloin joint.

To make the remoulade, mix together the yoghurt and mayonnaise until smooth. Finely chop the gherkins, capers and parsley. Finely dice the shallots and finely chop the chives. Add all of this to the yoghurt and mayonnaise mixture. Season the remoulade with lemon juice, salt and sugar to taste.

### Settings

#### Automatic programme

Meat | Beef | Sirloin joint | Roast

Programme duration: approx.

53 minutes

#### Manual

Oven functions: Conventional heat

Temperature: 180–190 °C

Core temperature: 45 °C (rare), 54 °C (medium), 75 °C (well-done)

Booster: On

Pre-heat: On

Crisp function: Off

Duration: approx. 35–45 minutes (rare), 45–55 minutes (medium), 55–65 minutes (well-done)

Shelf level: 2 [1] (1)

## Roast sirloin joint (low temperature cooking)

Total time required: 130 minutes

Serves 4

### For the sirloin

2 tbsp oil

1 tsp salt

Pepper

1 kg sirloin joint, ready to cook

### For frying

2 tbsp oil

### Accessories

Rack

Universal tray

Food probe

### Method

Put the rack on the universal tray and place in the oven. Start the automatic programme or special application.

Mix together the oil, salt and pepper; then coat the beef joint with it.

Heat the oil in a pan and sear the sirloin joint all over (approx. 1 minute per side).

Remove the sirloin joint from the pan and insert the food probe.

Place the sirloin joint on the rack and cook.

### Settings

#### Automatic programme

Meat | Beef | Sirloin joint | Low temp. cooking

Programme duration:  
approx. 117 minutes

#### Manual

Special applications | Low temp. cooking

Temperature: 80–100 °C

Core temperature: 45 °C (rare), 57 °C (medium), 66 °C (well-done)

Duration: approx. 60–80 minutes (rare), 100–130 minutes (medium), 130–160 minutes (well-done)

Shelf level: 2 [1] (1)

# Meat

---

## Yorkshire pudding

Total time required: 40 minutes

Makes 12

### Ingredients

12 tsp oil

190 g plain white flour

1 tsp salt

3 medium eggs

225 ml milk, 3.5 % fat

### Accessories

12-cup muffin tin with cup Ø 5 cm

Rack

### Method

Place 1 teaspoonful of oil in each muffin cup.

Place the muffin tin on the rack and put it in the oven. Start the automatic programme or pre-heat the oven using the settings indicated for cooking stage 1.

Mix together the flour and salt. Make a well in the centre. Add the eggs and use a whisk to slowly mix in the flour from around the edges.

Add milk and slowly mix to form a smooth batter.

As soon as the oven compartment has reached temperature, pour the batter out equally between the muffin cups.

Manual settings:

Adjust settings as indicated for cooking stage 2.

Bake until golden brown.

### Settings

#### Automatic programme

Meat | Beef | Yorkshire pudding

Programme duration:

28 [30] (22) minutes

#### Manual

Cooking stage 1

Oven functions: Fan plus (Conventional heat)

Temperature: 210 °C [210 °C] (250 °C)

Booster: On

Pre-heat: On

Crisp function: Off

Number/type of bursts of steam:

1 burst of steam/manual, immediately after placing the food in the oven

Shelf level: 2 [2] (1)

Cooking stage 2

Oven functions: Moisture plus + Fan plus

Temperature: 210 °C [210 °C] (225 °C)

Booster: On

Pre-heat: On

Crisp function: Off

Number/type of bursts of steam:

1 burst of steam/manual, immediately after placing the food in the oven

Duration: 26–30 [28–32]

(20–25) minutes

## **Come to the table!**

Many tasty meals flatter the taste buds far more than the figure, so it's comforting to know that fish dishes are notable exceptions to this and are every bit as healthy as they are tasty. In this chapter you will find a variety of fish specialities from around the world to enjoy.

# Fish

---

## Tips on preparation

Various operating modes are suitable for cooking fish, for example Moisture plus, Fan plus or Conventional heat.

The following tips will help you get the best results:

- Whole fish are ready when the eyeballs are white and the dorsal fin is easily pulled out.
- Roasted, steamed or grilled fish is cooked when the meat easily falls off the bones.
- Season fish to taste and dot with butter before putting it in the oven.
- Make sure that the metal tip of the food probe is inserted into the middle of the thickest part of the fish.
- If possible, insert the food probe behind the head of the fish parallel to the backbone.

## Sea bream

Total time required: 60 minutes

Serves 4

### Ingredients

800 g baby new potatoes  
4 whole sea breams (300 g each), ready to cook  
1 lemon, juice only  
Salt  
Lemon pepper  
2 red peppers, roughly chopped  
3 green or yellow courgettes cut into slices  
4 shallots cut into wedges  
3 finely chopped cloves of garlic  
300 g sheep's cheese chopped into cubes  
4 sprigs of rosemary  
4 sprigs of thyme  
10 tbs olive oil

### Accessories

Gourmet oven dish  
Food probe

### Method

Parboil the potatoes in their skins for about 10 minutes.

Pre-heat the oven.

Drizzle lemon juice over the sea breams. Season with salt and lemon pepper.

Mix together the potatoes, vegetables, sheep's cheese and sprigs of rosemary and thyme. Season with salt and lemon pepper and place in the Gourmet oven dish.

Place the sea bream onto the vegetables and insert the food probe. Place the Gourmet oven dish into the oven compartment and cook the sea bream.

### Settings

Oven functions: Moisture plus + Conventional  
Temperature: 170–180 °C  
Core temperature: 75 °C  
Booster: Off  
Pre-heat: On  
Crisp function: Off  
Number/type of bursts of steam: 2 bursts of steam/time-controlled, first after 5 minutes, second after 15 minutes  
Duration: approx. 30–45 minutes  
Shelf level: 2 [1] (1)

### Tip

Use baby new potatoes with a diameter of 2.5–4 cm.

# Fish

---

## Trout

Total time required: 65 minutes

Serves 4

### For the trout

4 trout (250 g each), ready to cook

2 tbsp lemon juice

Salt

Pepper

### For the filling

200 g fresh mushrooms

½ onion

1 clove of garlic

25 g parsley

Salt

Pepper

### For dotting

3 tbsp butter

### Accessories

Universal tray

Food probe

### Method

Drizzle the lemon juice over the trout.

Season with salt and pepper inside and out.

To make the stuffing, clean the mushrooms. Finely chop the onion, garlic, mushrooms and parsley, and mix well. Season the mixture with salt and pepper.

Start the automatic programme or pre-heat the oven.

Stuff the trout with the filling and place side-by-side on the universal tray.

Insert the food probe. Dot with small chunks of butter.

Place the universal tray in the oven compartment. Cook the trout.

### Settings

#### Automatic programme

Fish | Trout

Programme duration:

approx. 36 minutes

#### Manual

Oven functions: Moisture plus + Conventional

Temperature: 210–220 °C

Core temperature: 75 °C

Booster: Off

Pre-heat: On

Crisp function: Off

Number/type of bursts of steam:

1 burst of steam/time-controlled, first after 5 minutes

Duration: approx. 15–25 minutes

Shelf level: 2 [1] (1)

### Tip

Serve the trout with slices of lemon and browned butter.

## Salmon fillet

Total time required: 50 minutes

Serves 4

### Ingredients

4 salmon fillets (200 g each), ready to cook

2 tbsp lemon juice

Salt

Pepper

3 tbsp butter

1 tsp dill, chopped

### Accessories

Universal tray

Food probe

### Method

Start the automatic programme or pre-heat the oven.

Place the salmon fillets on the universal tray. Drizzle with lemon juice. Season with salt and pepper. Dot the salmon pieces with small chunks of butter and sprinkle with dill. Insert the food probe.

Place the universal tray in the oven compartment and cook the salmon fillets.

### Settings

#### Automatic programme

Fish | Salmon fillet

Programme duration:  
approx. 30 minutes

#### Manual

Oven functions: Moisture plus +  
Conventional

Temperature: 200–210 °C

Core temperature: 75 °C

Booster: Off

Pre-heat: On

Crisp function: Off

Number/type of bursts of steam:

1 burst of steam/time-controlled, first  
after 5 minutes

Duration: approx. 10–20 minutes

Shelf level: 2 [1] (1)

# Fish

---

## Salmon trout

Total time required: 65 minutes

Serves 4

### For the salmon trout

1 salmon trout (1 kg), whole, ready to cook

1 lemon, juice only

Salt

### For the filling

2 shallots

2 cloves of garlic

2 slices of white bread

50 g small capers

1 medium egg, yolk only

2 tbsp olive oil

Salt

Pepper

Chilli powder

### Accessories

Wooden skewers

Universal tray

Food probe

### Method

Drizzle the lemon juice over the salmon trout. Season with salt inside and out.

To make the stuffing, finely dice the shallots, garlic and bread. Mix together the capers, egg yolk, olive oil, shallots, garlic and bread. Season with salt, pepper and chilli powder.

Start the automatic programme or pre-heat the oven.

Stuff the salmon trout with the mixture. Seal the opening with small wooden skewers.

Place the salmon trout on a universal tray and insert the food probe. Place the universal tray in the oven compartment. Cook the salmon trout.

### Settings

#### Automatic programme

Fish | Salmon fillet

Programme duration:

approx. 52 minutes

#### Manual

Oven functions: Moisture plus + Conventional

Temperature: 210–220 °C

Core temperature: 75 °C

Booster: Off

Pre-heat: On

Crisp function: Off

Temperature: 160–180 °C

Number/type of bursts of steam:

1 burst of steam/time-controlled, first after 5 minutes

Duration: approx. 30–40 minutes

Shelf level: 2 [1] (1)

## Pollock fillet

Total time required: 70 minutes

Serves 4

### Ingredients

3 onions

40 g butter

500 g tomatoes

750 g pollock fillet, ready to cook

½ lemon, juice only

Salt

Pepper

100 ml milk, 3.5 % fat

1 tbsp breadcrumbs

2 tbsp parsley, chopped

### For the tin

1 tsp butter

### Accessories

Ovenproof dish, Ø 26 cm

Food probe

Rack

### Method

Cut the onions into thin slices and sauté in half of the butter. Slice the tomatoes.

Drizzle lemon juice over the pollock fillet. Season with salt and pepper.

Grease the ovenproof dish. Place the onions in the ovenproof dish. Layer the tomatoes on top. Season with salt and pepper. Place the pollock fillet on the tomatoes.

Place the rack in the oven. Pre-heat the oven.

Melt the rest of the butter. Pour the butter and milk over the pollock fillet. Sprinkle with the breadcrumbs. Insert the food probe.

Place in the oven compartment and cook.

Sprinkle with parsley and serve.

### Settings

Oven functions Moisture plus + Conventional

Temperature: 170–180 °C

Core temperature: 75 °C

Booster: Off

Pre-heat: On

Crisp function: Off

Duration: approx. 30–40 minutes

Type/number of bursts of steam:

2 bursts of steam/time-controlled, first after 5 minutes, second after

15 minutes

Shelf level: 2 [1] (1)

### Tip

Sea bream can also be used in this recipe instead of pollock.

# Fish

---

## Pike perch fillet on vegetables

Total time required: 30 minutes

Serves 4

### Ingredients

4 pike perch fillets (150 g each), ready to cook

1 lemon, juice only

Salt

Pepper

4 diced shallots

150 g cherry tomatoes

1 red pepper, diced into 1 cm pieces

1 yellow pepper, diced into 1 cm pieces

1 courgette, diced into 1 cm pieces

1 tbsp chopped mixed herbs

5 tbsp olive oil

### Accessories

Gourmet oven dish

### Method

Place the Gourmet oven dish in the oven. Start the automatic programme or pre-heat the oven.

Drizzle lemon juice over the fish fillets and season with salt and pepper.

Mix together the vegetables in a bowl. Season with salt, pepper and herbs.

Take the preheated Gourmet oven dish out of the oven compartment and coat it with olive oil. Arrange the vegetables in the Gourmet oven dish.

Place the Gourmet oven dish in the oven and cook.

Manual settings:

Adjust settings as indicated for cooking stage 2.

Place the fish fillets onto the vegetables and cook.

### Settings

#### Automatic programme

Fish | Pikeperch fillet with vegetables

Programme duration: 15 minutes

#### Manual

Cooking stage 1

Oven functions: Moisture plus + Fan plus

Temperature: 200 °C

Booster: On

Pre-heat: On

Crisp function: Off

Number/type of bursts of steam:

1 burst of steam/manual, first immediately after placing the food in the oven

Duration: 10 minutes

Shelf level: 3 [2] (3)

Cooking stage 2

Oven functions: Full grill

Pre-heat: Off

Crisp function: Off

Temperature: 240 °C

Duration: 5 minutes

### **The pleasure of your company**

When it comes to bakes and gratins, there are so many possibilities – you will struggle to find a dish with so many variations. The choice of ingredients is endless and you can combine them with seasonal produce and store-cupboard staples. What's more, they are incredibly easy to prepare and extremely popular with guests. And if you happen to have leftovers, they taste great after reheating.

# Bakes and gratins

---

## Swedish potato gratin

Total time required: 95 minutes

Serves 4

### For the bake

1 kg potatoes  
125 g Swedish anchovy fillets  
1 onion, sliced thinly  
200 ml double cream  
2 tbsp breadcrumbs

### For the tin

1 tsp butter

### Accessories

Grater, coarse  
Ovenproof dish, 29 cm x 21 cm  
Aluminium foil

### Method

Peel and cut the potatoes into fine matchsticks, or use a coarse grater. Grease the ovenproof dish.

Layer the potatoes, anchovies and sliced onions in the dish. Start and end with a layer of potatoes. Pour cream over and sprinkle with breadcrumbs.

Place the bake in the oven compartment and cook.

Cover with aluminium foil after 30 minutes to prevent the top from burning.

### Settings

#### Automatic programme

Bakes & gratins | Swedish potato gratin  
Programme duration: 67 minutes

#### Manual

Oven functions: Fan plus  
Temperature: 170–180 °C  
Booster: Off  
Pre-heat: Off  
Crisp function: Off  
Duration: 65–75 minutes  
Shelf level: 2 [1] (1)

### Tip

This is a traditional Swedish recipe.

## Potato gratin

Total time required: 70 minutes

Serves 4

### For the gratin

1 kg waxy potatoes cut into thin slices

400 ml double cream

Salt

Pepper

Nutmeg

50 g cheese, grated

### For the tin

1 tbsp butter

### Accessories

Porcelain ovenproof dish, capacity 3 l

Rack

### Method

Grease the ovenproof dish. Add the potato slices.

Season with salt, pepper and nutmeg and mix together with the potato slices.

Sprinkle cheese over the top.

Place the on the rack in the oven and bake until golden brown.

### Settings

#### Automatic programme

Bakes & gratins | Potato & cheese gratin

Programme duration: 50 minutes

#### Manual

Oven functions: Fan plus

Temperature: 180 °C

Booster: Off

Pre-heat: Off

Crisp function: Off

Duration: 50 minutes

Shelf level: 2 [1] (1)

### Tip

For a lighter dish, use a mixture of milk and cream.

# Bakes and gratins

---

## Potato and cheese gratin

Total time required: 90 minutes

Serves 4

### For the gratin

600 g floury potatoes

75 g grated gouda

### For the topping

250 ml double cream

1 tsp salt

Pepper

Nutmeg

### For sprinkling

75 g grated gouda

### For the tin

1 clove of garlic

### Accessories

Ovenproof dish, Ø 26 cm

Rack

### Method

Rub the ovenproof dish with the garlic clove.

To make the cream mixture, mix together the cream, salt, pepper and nutmeg.

Peel the potatoes and cut them into slices 3–4 mm thick. Mix the potatoes with the cheese and the cream mixture, and transfer to the ovenproof dish.

Sprinkle with the gouda.

Place the potato and cheese gratin on the rack in the oven and cook until golden brown.

### Settings

#### Automatic programme

Bakes & gratins | Potato & cheese gratin

Programme duration: approx.

58 minutes

#### Manual

Oven functions: Conventional heat

Temperature: 180–190 °C

Booster: Off

Pre-heat: Off

Crisp function: Off

Duration: 55–65 minutes

Shelf level: 2 [1] (1)

## Cheese soufflé

Total time required: 70 minutes

Serves 4

### For the soufflé

40 g butter

40 g plain white flour

375 ml milk, 3.5 % fat

100 g grated mature cheese (gruyere)

3 medium eggs

Salt

Pepper

### For the tin

1 tbsp butter

### Accessories

Soufflé tin, Ø 20 cm

Universal tray

### Method

Melt the butter. Add the flour. Add the milk while stirring constantly and bring to the boil to create a very thick béchamel sauce.

Leave the sauce to reduce for a few minutes while stirring constantly. Stir in the cheese.

Grease the soufflé tin. Separate the eggs and beat the egg whites until stiff.

Start the automatic programme or pre-heat the oven.

Beat the egg yolks into the slightly cooled béchamel cheese sauce. Fold in the egg whites carefully. Season with salt and pepper.

Pour the mixture into the soufflé tin. Place on the universal tray in the oven and pour about 1 litre (2 litres) of water into the universal tray.

### Settings

#### Automatic programme

Bakes & gratins | Cheese soufflé

Programme duration: 41 minutes

#### Manual

Oven functions: Fan plus

Temperature: 160–170 °C

Booster: On

Pre-heat: On

Crisp function: Off

Duration: 35–45 minutes

Shelf level: 2 [1] (1)

# Bakes and gratins

---

## Lasagne

Total time required: 125 minutes

Serves 4

### For the lasagne

8 lasagne sheets (not pre-cooked)

### For the bolognese sauce

2 diced onions

425 g mince, beef

800 g tinned tomatoes, skinned

30 g tomato purée

125 ml stock

1 tsp fresh thyme, chopped

1 tsp fresh oregano, chopped

1 tsp fresh basil, chopped

Salt

Pepper

### For the mushroom sauce

20 g butter

1 diced onion

100 g fresh mushrooms, sliced

2 tbsp plain white flour

250 ml double cream

250 ml milk, 3.5 % fat

Salt

Pepper

Nutmeg

2 tbsp fresh parsley, chopped

### For sprinkling

200 g grated gouda

### Accessories

Ovenproof dish, 32 cm x 22 cm

Rack

### Method

To make the bolognese sauce, start by heating a non-stick pan. Fry the mince. Add the onions and allow to sweat.

Add the tomatoes and allow to sweat.

Chop the tomatoes. Add the tomatoes,

tomato juice, tomato purée and stock. Season with herbs, salt and pepper. Allow to simmer for approx. 5 minutes.

To make the mushroom sauce, sweat the onions in butter. Add the mushrooms and sauté briefly. Sprinkle with flour and stir. Deglaze with the cream and milk. Season with nutmeg, salt and pepper. Allow the sauce to simmer for approx. 5 minutes. Finally, add the parsley.

To make the lasagne, layer up the ingredients in the ovenproof dish in the order listed below:

- One third of the bolognese sauce
- 4 lasagne sheets
- One third of the bolognese sauce
- Half of the mushroom sauce
- 4 lasagne sheets
- One third of the bolognese sauce
- Half of the mushroom sauce

Sprinkle the lasagne with the gouda and place it on the rack in the oven; cook until golden brown.

## **Settings**

### **Automatic programme**

Bakes & gratins | Lasagne

Programme duration:

60 [60] (58) minutes

### **Manual**

Oven functions: Conventional heat

Temperature: 185–195 °C

Booster: On

Pre-heat: Off

Crisp function: On

Duration: 55–65 minutes

Shelf level: 1

# Bakes and gratins

---

## Moussaka

Total time required: 100 minutes

Serves 6

### Ingredients

1.25 kg aubergines

Salt

90 ml olive oil

### For the meat sauce

3 tbsp oil

750 g mince, beef

1 diced onion

480 g tinned tomatoes (drained weight),  
chopped

2 tbsp fresh parsley, chopped

125 ml grape juice

Salt

Pepper

3 tbsp breadcrumbs

2 eggs, whites only

### For the béchamel sauce

40 g butter

40 g plain white flour

500 ml milk, 3.5 %

1 tsp salt

Pepper

Nutmeg

50 g grated gouda

2 eggs, yolks only

### For sprinkling

50 g grated gouda

### Accessories

Rack

2 baking trays

Kitchen roll

Ovenproof dish, 32 cm x 22 cm

### Method

Cut the aubergines lengthways into 1 cm-thick slices, sprinkle with salt and leave for approx. 20 minutes to draw out the liquid.

For the meat sauce, fry the mince in oil. Add the onions and continue to fry. Add tomatoes, parsley and grape juice. Season liberally with salt and pepper. Allow to simmer for approx. 15 minutes. Leave to cool slightly. To bind, fold in the breadcrumbs and egg white.

Preheat the oven using the indicated settings. Pat the aubergines dry with kitchen roll and lay across 2 baking trays. Brush both sides lightly with olive oil. Place the baking trays in the oven compartment and cook.

Turn the aubergines halfway through cooking and continue to cook until they have lightly browned.

For the béchamel sauce, heat the butter, stir in the flour and sweat. Deglaze with the milk. Leave the sauce to simmer for 5 minutes while stirring constantly. Season with nutmeg, salt and pepper. Remove the pan from the hob. Stir in the cheese and egg yolk.

Arrange half of the aubergines in the bottom of the ovenproof dish and then add the meat sauce on top. Then layer the rest of the aubergines and coat with the béchamel sauce. Sprinkle the remaining cheese on the moussaka.

Place on the rack in the oven and bake until golden.

## **Settings**

### **Cook aubergines**

Oven functions: Fan plus

Temperature: 200 °C

Booster: Off

Pre-heat: On

Crisp function: On

Duration: 20–25 minutes

Shelf level: 1 + 3 [1 + 2] (1 + 3)

## **Settings**

### **Automatic programme**

Bakes & gratins | Moussaka

Programme duration:

47 [47] (43) minutes

## **Manual**

Oven functions: Fan plus

Temperature: 170–180 °C

Booster: On

Pre-heat: Off

Crisp function: Off

Duration: 40–50 minutes

Shelf level: 2 [1] (1)

# Bakes and gratins

---

## Pasta bake

Total time required: 85 minutes

Serves 4

### For the pasta

150 g pasta (penne),  
cooking time indicated on pack:

11 minutes

1½ l water

3 tsp salt

### For the bake

1½ tbsp butter

2 diced onions

1 pepper, diced into 1 cm pieces

2 small carrots, sliced

150 ml crème fraîche

75 ml milk, 3.5 % fat

Salt

Pepper

300 g beef tomatoes, roughly diced

150 g sheep's cheese with herbs, diced

### For sprinkling

100 g grated gouda

### Accessories

Ovenproof dish, 24 cm x 24 cm

Rack

### Method

Cook the pasta in salted water for 5 minutes.

Heat butter in a saucepan and sauté the diced onions. Add the pepper and carrots and sauté for a further 5 minutes.

Mix together the crème fraîche and milk; then add to the vegetables. Season liberally with salt and pepper.

Place the pasta, tomatoes and sheep's cheese in the ovenproof dish. Stir in the vegetable sauce.

Sprinkle the pasta bake with gouda.

Place the pasta bake on the rack in the oven. Bake until golden brown.

### Settings

#### Automatic programme

Bakes & gratins | Pasta bake

Programme duration:

40 [38] (40) minutes

#### Manual

Oven functions: Fan plus

Temperature: 170–180 °C

Booster: Off

Pre-heat: Off

Crisp function: Off

Duration: 35–45 minutes

Shelf level: 2 [1] (1)

#### Tip

You can also make the bake with 350 g of cooked pasta left over from the previous day.

## Shepherd's pie

Total time required: 100 minutes

Serves 8

### For the bake

2 finely chopped onions  
2 diced carrots  
2 sticks of celery cut into small pieces  
1 kg minced lamb  
½ tsp fresh thyme, finely chopped  
½ tsp fresh rosemary, finely chopped  
1½ tsp tomato purée  
1 tbsp plain white flour  
450 ml chicken stock  
1 tbsp Worcestershire sauce  
Salt  
Pepper  
1.5 kg floury potatoes, diced  
25 g butter  
5 tbsp milk, 3.5 % fat

### For frying

2½ tbsp butter

### Accessories

Ovenproof dish, capacity 2.5 l

### Method

Heat the butter in a pan. Sauté the onions for 2–3 minutes. Add the carrots and celery and sweat for another 8–10 minutes. Add the minced meat and brown, stirring constantly. Drain off any excess fat and add the thyme, rosemary and tomato purée.

Reduce to about 1/4 on a medium heat, sprinkle in the flour and simmer for a further 2–3 minutes.

Add the stock and Worcestershire sauce and simmer for 45–50 minutes. Season with salt and pepper to taste.

While the meat is simmering, mash the potatoes together with the butter and milk.

Place the meat mixture in the ovenproof dish and top with the mashed potato. Place in the oven and bake until golden brown.

### Settings

#### Automatic programme

Bakes & gratins | Shepherd's pie  
Programme duration: 50 minutes

#### Manual

Oven functions: Fan plus  
Temperature: 180 °C  
Booster: Off  
Pre-heat: Off  
Crisp function: Off  
Duration: 50 minutes  
Shelf level: 2 [1] (1)

### Tip

For Cottage pie use minced beef instead of lamb.

# Dessert

---

## **All's well that ends well**

It's true what they say – no one can resist a delicious dessert. An ice cream, soufflé or fruity confection is the perfect end to a meal, yet requires relatively little effort to make. Indeed, the most successful desserts are often those that need the least preparation.

## Viennese apple strudel

Total time required: 70 minutes

For 2 strudels

### Ingredients

100 g breadcrumbs  
4 strudel pastry sheets (pre-packed)  
100 g melted butter  
1.5 kg apples, thinly sliced  
150 g caster sugar  
50 g raisins  
Cinnamon

### For frying

50 g butter

### Accessories

2 tea towels  
Baking tray or universal tray

### Method

Heat the butter in a pan and lightly fry the breadcrumbs.

Place 2 strudel pastry sheets on top of each tea towel so that they overlap slightly.

Brush the strudel pastry with half the butter and sprinkle with breadcrumbs.

Mix the apples together with the sugar, raisins and cinnamon. Place the apple mixture onto the breadcrumbs.

Start the automatic programme or pre-heat the oven.

Roll up the strudels and brush with remaining melted butter. Place onto the baking tray or universal tray, place in the oven compartment and bake until golden brown.

### Settings

#### Automatic programme

Dessert | Viennese apple strudel  
Programme duration: 45 minutes

#### Manual

Oven functions: Intensive bake  
Temperature: 170 °C  
Pre-heat: On  
Crisp function: On  
Duration: 40–50 minutes  
Shelf level: 2 [1] (2)

# Dessert

---

## Chocolate sponge puddings

Total time required: 70 minutes

Serves 8

### For the batter

70 g dark chocolate

70 g butter

70 g sugar

4 medium eggs

70 g ground almonds

20 g breadcrumbs

500 ml vanilla custard

200 ml double cream

### For dusting

40 g icing sugar

### For the tin

1 tsp butter

### Accessories

8 ramekins, Ø 6 cm

Universal tray

Fine sieve

### Method

Melt the chocolate over a low heat on the hob and then leave to cool slightly.

Beat the butter, sugar and egg yolks until creamy. Stir in the chocolate, the almonds and the breadcrumbs.

Start the automatic programme or pre-heat the oven.

Beat the egg whites to stiff peaks, then carefully fold into the chocolate mixture.

Grease the ramekins. Spoon in the mixture.

Place the ramekins on the universal tray in the oven. Cook.

Whip the cream until stiff and fold into the custard. Divide evenly between the dessert plates.

Run a knife around the edge of the chocolate sponge puddings to loosen them. Place one sponge pudding on each dessert plate. Dust with icing sugar and serve lukewarm.

### Settings

Oven functions: Conventional heat

Temperature: 150–160 °C

Booster: Off

Pre-heat: On

Crisp function: Off

Duration: 35–45 minutes

Shelf level: 1





# Miele

## **Miele Saudi Arabia**

**AWAD BADI NAHAS TRADING CO. LTD**

### **Head Office:**

#### **Jeddah**

P.O. Box 11529 Jeddah 21463

Tel. +966 12 2560888, Fax. +966 12 2560555

Hotline for customer care: 920003240

Website: [www.awadnahas.com](http://www.awadnahas.com)

### **Branches:**

#### **Jeddah**

Madina Road

Tel. +966 12 6970060, Fax. +966 12 6970012

#### **Jeddah**

Sitteen Street

Tel. +966 12 6611675, Fax. +966 12 6606852

#### **Jeddah**

Miele Gallery

Al Thanyyan Group Building, Al-Madina Road,  
Near, Al Rowdah District, Jeddah

Tel. +966 12 6989339 Ext. 100

Fax. +966 12 6989339 Ext. 200

#### **Riyadh**

Olaya Street

Tel. +966 11 2013501, Fax. +966 11 2013502

#### **Taif**

Hadiya Street

Tel. +966 12 7327001, Fax. +966 12 7369596

#### **Khobar**

Al Zahran Road

Tel. +966 13 8646150, Fax. +966 13 8646190

## **Miele United Arab Emirates**

Miele Appliances Ltd.

Showroom 1

Eiffel 1 Building

Sheikh Zayed Road, Umm Al Sheif

P.O. Box 114782 - Dubai

United Arab Emirates

Tel. +971 4 3044 999

Fax. +971 4 3418 852

800-MIELE (64353)

E-Mail: [info@miele.ae](mailto:info@miele.ae)

Website: [www.miele.ae](http://www.miele.ae)

Webshop: [shop.miele.ae](http://shop.miele.ae)

**Manufacturer:** Miele & Cie. KG, Carl-Miele-Straße 29, 33332 Gütersloh, Germany

